

ASSEMBLY INSTRUCTION

ITEM#: 1203060004-G



For any questions or issues about our product

Call Sunjoy Customer Service

1(866) 578-6569

anytime 24 hours 7 days a week

Country of Origin: China

Safety Information

- Please follow the simple step-by-step assembly Instructions.
- Check and ensure all the parts, fittings and hardware are present before discarding any packaging.
- One or two people are required for this assembly.
- Please read all instructions carefully before assembly and usage. Basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.
- Advisable to wear protective gloves during assembly.
- Assemble this product on the flat surface.
- Assemble all parts loosely before tightening any bolts.
- Retain this Assembly Instruction for future reference.



CAUTION: Do not climb on top of the product. Falling off the product may result in serious injury.


NOTICE: For indoor use only

Warranty: 1 Year

WHAT IS COVER?

The limited warranty is extended to the original purchaser and applies to material and manufacturer's defect provided the item is maintained with care and used only for personal, residential purposes.

TOOLS NEEDED




Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com


IMPORTANT

KEEP THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE.

ONE OR TWO PERSON IS/ARE NEEDED FOR THE INSTALLATION WORK.












EXPLODED DRAWING













Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com

Parts List				
Part	Part Number	Description	Qty	Part Image
#1	P12304A10013	Table top	1	
#2	P02301A10013	Connection Frame 1	1	
#3	P02302A10013	Connection Frame 2	1	
#4	P21104A10013	Left Panel	1	
#5	P21105A10013	Right Panel	1	
#6	P02401A10013	Riser 1	2	
#7	P02402A10013	Riser 2	1	
#8	P11704A10013	Shelf	1	
#9	P20602A10013	Base Panel	1	





Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com

#10	P02103B10013	Towel Bar Holder	2	
#11	P02103A10013	Towel Bar	1	
#12	P90004A10013	Wood Knob	2	
#13	P02201B10013	Card Slot	2	
#14	P21205A10013	Back Panel 1	1	
#15	P21204A10013	Back Panel 2	3	
#16	P20902B10013	Door	1	
#17	P20902A10013	Left door	1	
#18	P20903A10013	Right door	1	
#19	P21306A10013	Front Dower Panel	3	





















Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com

#20	P21307B10013	Left Dower Panel	3	
#21	P21308B10013	Right Dower Panel	3	
#22	P21303C10013	Back Dower Panel	3	
#23	P21303D10013	Bottom Dower Panel	3	



















Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com





Hardware pack					
Part	Part Number	Description	Qty	Add	Part Image
AA	H06037C13	Bolt M6*37	14	2	  Actual Size
BB	P90602A01002	Multi Fit Ø 10*12	6	1	
CC	H07047K13	Screw M5*47	4	1	  Actual Size
DD	H11030J12	Screw M4*30	38	4	  Actual Size
EE	P90103A01002	Cam Bolt M6*35	2	1	
FF	P90103B01002	Cam Ø 15	2	1	
GG	P90402A10000	Dowel Ø 5.5*30	34	4	
HH	P90501B07011	Shelf Pin Ø 6	4	0	
JJ	H11010J12	Screw M4*12	16	2	  Actual Size
KK	P90201B02000	Door Hinge	4	0	
LL	P90005A03000	Door Knob	6	0	
MM	H09020A12	Bolt M4*20	6	1	  Actual Size
NN	P02501A01002	Guide Frame	1	0	
PP1	P11801B01011	Left Support Panel	1	0	
PP2	P11802B01011	Right Support Panel	1	0	

Country of Origin: China




Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com

QQ	P02601A01008	Garbage Bag Rack	2	0		
RR	H18010A12	Bolt M4*10	4	1		 Actual Size
SS	H12001A12	Spring Washer M4	4	1		 Actual Size
TT	H14001A12	Nut M4	4	1		 Actual Size
UU	H10010J13	Screw M4*12	8	1		 Actual Size
VV1	P90304B01002	Caster Wheel	2	0		
VV2	P90304A01002	Caster Wheel With Lock	2	0		
WW	H10015K13	Screw M5*15	16	2		 Actual Size
XX1	H00001A12	Wrench M4	1	0		
YY	P91101A07000	Magnetic touch	1	0		
ZZ	H11015P12	Screw M3*15	2	1		 Actual Size
XX2	H00002C12	Allen Key Size 4	1	0		



STEP 1 : Assembling the Towel Bar









STEP 2 : Connecting the Towel Bar and Right Panel




STEP 3 : Assembling the Drawer Pane





STEP 4 : Attaching the Bottom and the Back Drawer Panel



STEP 5 : Assembling the Door Knob




STEP 6 : Assembling the Door






Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com


STEP 7 : Assembling the Connection Frame 2 and Riser 1





STEP 8: Assembling the Connection Frame 1






STEP 9 : Attaching the Right Panel and the Connection Frame







STEP 10 : Assembling the Back Panel 1







STEP 11: Assembling the Left Panel




STEP 12: Attaching the Riser 2






STEP 13: Attaching the Table Top







STEP 14: Attaching the Base Panel







6x	10x	6x
AA	GG	BB
H06037C13	P90402A10000	P90602A01002








STEP 15: Attaching the Caster Wheel







STEP 16: Attaching the Guide Frame






STEP 17: Attaching the Support Pane






STEP 18: Attaching the Door




STEP 19: Attaching the Garbage Bag Rack







STEP 20: Attaching the Table Top




STEP 21: Attaching the Door and Door Hinge



STEP 22: Attaching the Shelf



STEP 23 : Placing the Drawer



Country of Origin: China

Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com

Care and Maintenance

- Wood is a natural material. The appearance of the wood will age with time when it is exposed to extreme weather. A surface coating is vital to protect it from premature aging or splitting.
- The finish should be regularly maintained to ensure that the wood is protected from moisture and the furniture continues to look its best
- Apply wood oil on the product surface with a clean cloth every 6 weeks or earlier depending on weather conditions.
- Treat all surfaces of the product including the 'hard to get to' and hidden surfaces with extra attention given to the joints and end grains.
- Protect this product from severe weather and store it under cover during winter with a liberal coat of wood oil.
- Before using, clean the product completely with soft, dry towel. When not in use, wipe free of any dirt or loose dust, wash with a mild solution of soap and water; rinse thoroughly and dry completely.
- Do not use strong detergent or abrasive cleaners
- Moisture and heat can damage any wood finish. Protect your furniture surface by using coasters and trivets. Always wipe up moisture promptly and dry with a soft cloth.
- Protecting furniture from natural elements. When not in use, protection covering are highly recommended.
- Avoid dragging sharp or rough objects across the surface of your wood furniture. Use adhesive felt pads, trivets, coasters and placemats to help prevent scratches.
- Wood will expand and contract with seasonal humidity changes.
- Over time, air and sunlight will change the colour of natural wood. Occasionally rotate the items placed on your wood furniture to allow a more uniform colour to develop.
- Care for your wood furniture according to its finish.
- Clean with damp cloth whenever necessary.
- Periodically check and ensure that all bolts are well-tighten during use
- Should any scratching or damage occur, we recommend immediate touch-up oil or appropriate touch-up paint.

Limited Manufacturer's Warranty

Sunjoy Group warrants to the original purchaser that this item is free from defects in workmanship and materials for a period of **1 year** from the date of purchase, provided the item was factory-sealed at the time of purchase and is maintained with care and used only for personal, residential purposes. Should any manufacturing defect arise within this warranty period, Sunjoy Group will replace (at our option) any defective merchandise or parts upon proof of purchase; however, transportation and delivery costs, as well as payments to a third party for assembly or disassembly of the item, remain the responsibility of the purchaser. A purchaser of an "open box," previously-returned, or "clearance" item, as well as original purchasers outside of the warranty period, may obtain replacement parts from Sunjoy Group for products in current production, at nominal cost.

Exclusions:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

Country of Origin: China

**Call 1(866)578-6569 for assistance.
Or visit us at www.sunjoyonline.com**