



**SWITCH ASSORTMENT**



**SPST**

**SPDT**

**SPTT**

**DPST**

**DPDT**

**DPTT**



## TOGGLE

Commonly used on:

- Power Tools
- Marine
- Panel Controls
- Motors
- Appliances
- Grinders



## PUSH BUTTON

Commonly used on:


- Door Bells
- Lamps
- Control Panels
- Farm/Agriculture
- Buzzers
- Appliances



## ROTARY

Commonly used on:


- Lighting
- Electrical Equipment
- Ceiling Fixtures
- Industrial Controls
- Entertainment Systems
- Musical Instrument Controls



## PULL CHAIN

Commonly used on:


- Ceiling Fan
- Neon Signs
- Lighting
- Ceiling Fixtures



## DOOR/CABINET

Commonly used on:

- Doors
- Closets
- Cabinets
- RVs
- Windows
- Furnaces






























## ROCKER

Commonly used on:

- Ovens
- Appliances
- Lighting
- Computer Equipment
- Industrial Controls
- Marine

SPST	DPST	SPDT	DPDT	SPTT
<p>A switch that makes or breaks the connection of a single conductor in a single branch circuit. This switch has two terminals that are either connected together or disconnected.</p> <p>ONE CIRCUIT - ON/OFF</p>	<p>A switch that makes or breaks the connection of two conductors in a single branch circuit. This switch has four terminals and is the equivalent of two SPST switches controlled by a single mechanism.</p> <p>TWO CIRCUITS - ON/OFF</p>	<p>A switch that makes or breaks the connection of a single conductor with either of two other single conductors. This switch has 3 terminals and is commonly referred to as a "Three-Way" switch.</p> <p>ONE CIRCUIT - ON/OFF/ON</p>	<p>A switch that makes or breaks the connection of two conductors to two separate circuits. This switch has six terminals and is the equivalent to two SPDT switches controlled by a single mechanism.</p> <p>TWO CIRCUITS - ON/OFF/ON</p>	<p>A switch that makes or breaks the connection of a single conductor with either of three other single conductors or either or both of two conductors.</p> <p>ONE CIRCUIT - OFF/ON(A)/ON(B)/ON(A+B)</p>

	<b>PART #</b>	<b>DESCRIPTION</b>	<b>VAC</b>	<b>POLES &amp; THROWS</b>	<b>TERMINAL TYPE</b>	<b>UPC</b>
	<b>GSW-10</b>	Toggle Switch	20A 125V AC	<b>SPST</b>	Screw	032076899547
	<b>GSW-11</b>	Toggle Switch, with On/Off Faceplate	20A 125V AC	<b>SPST</b>	Screw	032076890117
	<b>GSW-110</b>	Toggle Switch	20A 125V AC	<b>SPST</b>	Screw	032076021047
	<b>GSW-111</b>	Toggle Switch, Bat Handle	20A 125VAC	<b>SPST</b>	Screw	032076922764
	<b>GSW-114</b>	Toggle Switch, Double Insulated	20A 125V AC	<b>SPDT</b>	Spade	032076021085
	<b>GSW-115</b>	Toggle Switch	20A 125V AC	<b>DPDT</b>	Spade	032076922924
	<b>GSW-117</b>	Toggle Switch	20A 125V AC	<b>SPDT</b>	Screw	032076021184
	<b>GSW-12</b>	Toggle Switch	20A 125V AC	<b>SPST</b>	Screw	032076890124
	<b>GSW-120</b>	Toggle Switch	20A 125V AC	<b>SPDT</b>	Spade	032076021214
	<b>GSW-121</b>	Toggle Switch	20A 125V AC	<b>SPST</b>	Spade	032076021221
	<b>GSW-121L</b>	Toggle Switch, Long Shank	6A 125V AC	<b>SPST</b>	Screw	032076923006
	<b>GSW-122</b>	Toggle Switch, O-Ring	20A 125V AC	<b>DPDT</b>	Spade	032076021238
	<b>GSW-123</b>	Toggle Switch	20A 125V AC	<b>DPDT</b>	Screw	032076021245
	<b>GSW-124</b>	Toggle Switch, Short Ball	6A 120V AC	<b>SPST</b>	Screw	032076021740
	<b>GSW-125</b>	Toggle Switch	6A 125V AC	<b>SPST</b>	Wire Leads	032076021757
	<b>GSW-125BP</b>	Toggle Switch, Short Ball	6A 125V AC	<b>SPST</b>	Wire Leads	032076036720
	<b>GSW-126</b>	Toggle Switch, O-Ring	10A 125V AC	<b>DPDT</b>	Spade	032076922788
	<b>GSW-127</b>	Toggle Switch, Heavy Duty	15A 125V AC	<b>SPST</b>	Spade	032076922832
	<b>GSW-13</b>	Toggle Switch	20A 125V AC	<b>SPDT</b>	Screw	032076890131
	<b>GSW-14</b>	Toggle Switch	20A 125V AC	<b>DPST</b>	Screw	032076890148
	<b>GSW-140</b>	Toggle Switch	20A 125V AC	<b>DPST</b>	Spade	032076922948
	<b>GSW-143</b>	Toggle Switch	20A 125V AC	<b>DPDT</b>	Spade	032076922962
	<b>GSW-15</b>	Toggle Switch	20A 125V AC	<b>DPST</b>	Screw	032076890155
	<b>GSW-151</b>	Slide Switch	6A 125V AC	<b>SPST</b>	Solder	032076923020
	<b>GSW-16</b>	Toggle Switch	20A 125V AC	<b>DPDT</b>	Screw	032076890162
	<b>GSW-17</b>	Toggle Switch	6A 120V AC	<b>SPST</b>	Screw	032076890179
	<b>GSW-18</b>	Toggle Switch	10A 120/125V AC	<b>SPST</b>	Wire Leads	032076890186
	<b>GSW-19</b>	Toggle Switch, Double Insulated	20A 125V AC	<b>SPST</b>	Screw	032076890193
	<b>GSW-20</b>	Toggle Switch Cover	-	-	-	032076890209
	<b>GSW-20H</b>	Toggle Switch Cover, Half Boot	-	-	-	032076922740
	<b>GSW-21</b>	Push Button Switch	10A 125V AC	<b>SPST</b>	Wire Leads	032076890216
	<b>GSW-22</b>	Push Button Switch, Momentary	6A 120V AC	<b>SPST</b>	Screw	032076890223
	<b>GSW-23</b>	Push Button Switch, Momentary	3A 120V AC	<b>SPST</b>	Screw	032076890230
	<b>GSW-24</b>	Push Button Switch, Nickel	6A 125V AC	<b>SPST</b>	Wire Leads	032076894498
	<b>GSW-24BP</b>	Push Button, Nickel	6A 125V AC	<b>SPST</b>	Wire Leads	032076036461
	<b>GSW-25</b>	Push Button Switch, Momentary	6A 125V AC	<b>SPST</b>	Wire Leads	032076894504
	<b>GSW-26</b>	Door Switch Kit	16A 125V AC	<b>SPST</b>	Wire Leads	032076895600
	<b>GSW-31</b>	Pull Chain Switch, Single Circuit	6A 125V AC	<b>SPST</b>	Wire Leads	032076890315
	<b>GSW-31BP</b>	Pull Chain Switch, Nickel	6A 125V AC	<b>SPST</b>	Wire Leads	032076036485
	<b>GSW-32</b>	Pull Chain Switch, Brass	6A 125V AC	<b>SPST</b>	Wire Leads	032076890322
	<b>GSW-32BP</b>	Pull Chain Switch, Brass	6A 125V AC	<b>SPST</b>	Wire Leads	032076036713
	<b>GSW-33</b>	Pull Chain Switch, 2 Speed	6A 125V AC	<b>SPDT</b>	Wire Leads	032076890339
	<b>GSW-34</b>	Pull Chain Switch, 3- Speed	6A 125V AC	<b>SPTT</b>	Wire Leads	032076890346
	<b>GSW-35</b>	Pull Chain Switch, All Angle	6A 125V AC	<b>SPST</b>	Wire Leads	032076021009
	<b>GSW-39</b>	Pull Chain Switch, 3 Speed	6A 125V AC	<b>SPTT</b>	Wire Leads	032076039004

	PART #	DESCRIPTION	VAC	POLES & THROWS	TERMINAL TYPE	UPC
	<b>GWS-41</b>	Appliance Rocker Switch	16A 125V AC	<b>SPST</b>	Spade	032076890414
	<b>GWS-42</b>	Appliance Rocker Switch, Illuminated	16A 125V AC	<b>SPST</b>	Spade	032076890421
	<b>GWS-45</b>	Rocker Switch	20A 125V AC	<b>SPST</b>	Spade	032076021030
	<b>GWS-46</b>	Rocker Switch	20A 125V AC	<b>DPDT</b>	Spade	032076922696
	<b>GWS-47</b>	Rocker Switch, Lockout	20A 125V AC	<b>SPST</b>	Spade	032076923044
	<b>GWS-48</b>	Rocker Switch, Red Mini	16A 125V AC	<b>SPST</b>	Spade	032076021139
	<b>GWS-49</b>	Rocker Switch, Red Lighted	20A 125VAC	<b>SPST</b>	Spade	032076042974
	<b>GWS-50</b>	Rocker Switch, Square, Illuminated	16A 125V AC	<b>SPST</b>	Spade	032076920173
	<b>GWS-51</b>	Rocker Switch, Round Hole	16A 125V AC	<b>SPST</b>	Spade	032076920197
	<b>GWS-61</b>	Rotary Switch	6A 125V AC	<b>SPST</b>	Wire Leads	032076890612
	<b>GWS-62</b>	Rotary Switch	6A 125V AC	<b>SPTT</b>	Wire Leads	032076890629
	<b>GWS-63B</b>	Rotary Switch, Black Plastic	6A 125V AC	<b>SPST</b>	Wire Leads	032076021160
	<b>GWS-63W</b>	Rotary Switch, White	3A 125V AC	<b>SPST</b>	Wire Leads	032076923068
	<b>GWS-64</b>	Rotary Switch, Plastic Knob	4A 125V AC	<b>SPTT</b>	Spade	032076021177
	<b>GWS-68</b>	Rotary Switch, Brass	6A 125V AC	<b>SPTT</b>	Wire Leads	032076043025
	<b>GWS-69</b>	Rotary Switch, Black Plastic	6A 125V AC	<b>SPST</b>	Wire Leads	032076043032
	<b>GWS-69BP</b>	Rotary Switch	6A 125V AC	<b>SPST</b>	Wire Leads	032076038960
	<b>GWS-ACC</b>	Accessory Pack, Switches	-	-	-	032076923082
	<b>GWS-AS</b>	Alarm Switch/Sensor/Magnetic	0.25A 125V AC	<b>SPDT</b>	Screw	032076923105
	<b>GWS-KS</b>	Shorting Toggle, On-Ground	21A 14V DC	<b>SPST</b>	Spade	032076922986
	<b>GWS-MS</b>	Micro Switch, Snap-In	15A 125V AC	<b>SPDT</b>	Spade	032076923129
	<b>GWS-RSC</b>	Refrigerator Switch, Momentary, Normally On	5A 125V AC	<b>SPST</b>	Spade	032076923167
	<b>GWS-RSF</b>	Refrigerator Switch, Momentary, Normally Off	5A 125V AC	<b>SPST</b>	Spade	032076923181
	<b>GWS-SK</b>	Door Switch Kit	16A 125V AC	<b>SPST</b>	Wire Leads	032076897475
	<b>GWS-71</b>	Cord Switch, Brown	6A 125V AC	<b>SPST</b>	Insulation Displacement	032076922665
	<b>GWS-72</b>	Cord Switch, White	6A 125V AC	<b>SPST</b>	Insulation Displacement	032076922726

# SWITCH COUNTER DISPLAY (DPA-1003)



**DISPLAY CONTAINS 2 OF EACH SKU**

<b>GWS-SK</b>	<b>GWS-124</b>	<b>GWS-45</b>	<b>GWS-110</b>
<b>GWS-34</b>	<b>GWS-13</b>	<b>GWS-61</b>	<b>GWS-125</b>
<b>GWS-22</b>	<b>GWS-19</b>	<b>GWS-62</b>	<b>GWS-122</b>
<b>GWS-21</b>	<b>GWS-16</b>	<b>GWS-11</b>	<b>GWS-24</b>
<b>GWS-25</b>	<b>GWS-50</b>	<b>GWS-18</b>	<b>GWS-31</b>
<b>GWS-41</b>	<b>GWS-121</b>	<b>GWS-14</b>	
<b>GWS-42</b>	<b>GWS-51</b>	<b>GWS-32</b>	

**TOTAL: Switch Display - Free Display, Hooks & Header!**