LED NUC-4 Linkable INSTALLATION INSTRUCTIONS



CAUTION

1. Read all instructions carefully for safe operation and installation.

2. To avoid possible electrical shock, shut off electricity before the installation.

3. All wiring must be in accordance with national and local electrical codes. Installation work and electrical wiring must be done by a qualified electrician.

4. Do not install over a heat source.

Model	Electrical Rating	Max Units	Max Distance Between Units
NUC-4-08-DM-L-##	120 Vac, 60 Hz, 0.038A		
NUC-4-12-DM-L-##	120 Vac, 60 Hz, 0.057A		
NUC-4-21-DM-L-##	120 Vac, 60 Hz, 0.083A	30	72″
NUC-4-30-DM-L-##	120 Vac, 60 Hz, 0.110A		
NUC-4-40-DM-L-##	120 Vac, 60 Hz, 0.145A		

What's In The Box

One (1) LED Under Cabinet





Tools Needed

This LED Under Cabinet requires very few tools for installation. A Phillips Head Screwdriver will be needed to install the fixture to cabinetry.



Optional Accessories





Installing Under Cabinets

