



Item #13022

SwimWays Spring Float Recliner with Canopy

Thank you for purchasing the SwimWays Spring Float Recliner with Canopy. At SwimWays our mission is to make your free time more fun through innovation by creating exciting products for you and your family.

Product Features

- The ultimate free-floating experience with headrest, backrest, ottoman and cup holder
- The perfect float for relaxing and socializing with friends
- Removable canopy provides shade and sun protection
- Patented Inner Spring Technology for greater comfort and stability

Product Instructions

TO INFLATE

1. Remove valve cap and pull out stem to open.
2. Inflate 2 air chambers.
3. Immediately cover valve opening and press down firmly.
4. Replace valve cap.

TO DEFLATE AND STORE

1. Remove valve cap and pull out stem to release air. Deflate float before folding.
2. Hold float as shown, palms facing out. Bring your hands together in front of you.
3. Overlap your hands and float will automatically close into 3 small circles.



WARNING: This is not a lifesaving device. Always keep children in sight within quick and easy reach when they are in the water with you. Open item slowly to avoid sudden movement. Not for use by children 15 and under. Not for commercial use. Do not attempt to jump on item or hold small children while lying on the product.

Ages: 15+

Supports up to 250 lbs.

**Questions? Call SwimWays Customer Service
8:30 a.m. - 5 p.m., EST, Monday-Friday**

**1.800.889.SWIM (7946)
www.swimways.com**

Please retain this sheet for future use.