

# Overview

**Note:** In order to set up the system, items will need to be retrieved from inside of the X-Boost Power Box.

1. Lower the carry handle by pressing the locking tabs on either side of the handle.
2. Open the Power Box (a). Open the air hose retainer (b) inside the cover and retrieve the air hose and handle assembly (c). Close the air hose retainer.
3. Unwrap the power cord. Slide the power cord grommet into the provided recess.


**IMPORTANT: Do not close the Power Box cover if the power cord grommet is not positioned correctly. The power cord could be damaged.**

4. Remove the desired spray nozzle from inside the Power Box\*. Close the cover and pull the carry handle upwards. This will make the nozzle holder accessible during usage.


## \*Nozzle Selection:

**Note:** Your unit includes two spray nozzles. See below to determine the correct nozzle for your spraying project.

- **Detail Finish Nozzle - used for small projects and fine finishing.** Designed for spraying thinner materials, such as water- and oil-based stains and thinned paints. The Detail Finish Nozzle leaves a smooth finish.



- **iSpray Nozzle - used for broad surface coating.** Designed for spraying thicker materials, such as latex paints and stains. Spraying with this nozzle will leave a slightly coarser finish that is between a roller and fine-finish sprayer.



**Note:** These two spray nozzles have different spray pattern / width controls. Make sure to familiarize yourself with the controls on each spray nozzle. See the "Controls" section, page 8-9.

