




Replacement Parts List

Kiso 4 in. Centerset Single Handle Low-Arc Bathroom Faucet in Chrome

MODEL	STORE SKU #	FINISH
67733W-6001	654181	Polished Chrome



Faucet ID tags can be found on the hot water inlet

Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Handle	RP1346701		
2	Set screw	RP50002	302559230	
3	Index	RP8039001		
4	Cap	RP8055101		
5	Bonnet nut	RP70224		
6	Cartridge & Screw	RP20078	301158148	
7	Flange	RP8054801		
8	Deck plate	RP8054901		

Part	Description	Part #	Internet SKU #	Store SKU #
09	Gasket	RP80550		
10	Rubber washer	RP64008		
11	Metal washer	RP64009		
12	Lock nut	RP56111		
13	ClickInstall™ Drain Assembly	RP4022801		
14	Lift rod	RP4023001		