

INTRODUCTION



Thank you for purchasing this indoor tabletop fountain. You have purchased a product that complies with the latest design and with a creative theme.




This product is carefully packaged, inspected, and tested to ensure safe operation and delivery. The following instructions and safety guidelines will enable you to use the product for trouble-free operation. Please read the instructions and safety guidelines entirely before using the product.

INSTRUCTION MANUAL

Product Feature: The product consists: (1) Poly Fountain body ; (2) Fountain base ; (3) Pump .
(Please read pump use manual).

Instructions for use:

1. Unpack the product. Read this instruction sheet before proceeding.
2. Familiarize yourself with the pump. The pump speed is controlled by the switch located at the front of the pump. The speed is indicated by plus(+) and minus (-) sign. To increase the speed, move to each speed level. At its highest speed level, the switch will cease to move any further, vice versa.
3. Place the product on a flat surface, remove plastic bag from packaging.
4. Insert the pump into the water tube from the fountain body, then connect the male jack with female jack.
5. Fill base pond with tap water to 1cm from the edge of the base. Make sure there is no solid impurity in the water, or it will affect the pumps work;
6. Insert the adaptor plug into the power socket, If installed properly, water will begin flowing. Please note: **On first use, there may be air in the pump, It can take up to a few minutes until the air escapes.**



Safety Guidelines:

1. Read all instructions and safety guidelines thoroughly. Failure to follow guideline and instructions could result in serious injury and/or property damage.
2. Do not pump flammable liquids such as gasoline / fuel oil with the fountain pump.
3. Make sure the water tube is properly connected with the pump and the upper layer, and do not crimp the tube otherwise water will not come out.
4. During operation, the area around the pump will be covered with water. Take care when handling the pump; do not pull pump out of water (when running) by the power cord, and do not move the product when running.
5. Unplug pump and power before servicing, cleaning, or moving.

Cleaning and Maintenance:

1. If after time the pump starts to lose power or stops working you should check for the build up of sediment or scale at the bottom of the pump housing or in reservoir.
2. Remove the impeller or any dirt and scale, which has built up and close the case back up.
3. Periodically change water and keep water clean. We recommend distilled water to prevent mineral build-up.

This instruction relates ONLY to this water fountain product and contains important information for using the product for the first time. Please keep it for later reference. This instruction should always accompany the product in the event of transfer to