


Operations



To operate the tub filler simply move the handle to the ON position to turn on the water. Adjust the temperature by moving the handle from side to side to set the desired water temperature.

To operate the hand shower wand, remove the hand shower from its holder and direct the jets into the tub. Pull the diverter knob on the faucet body. Push the diverter knob to direct the water back to the spout.

Parts

01. Aerator Assembly
02. Hand Shower Wand
03. Diverter Knob
04. Hand Shower Hose
05. Hot and Cold Water Supply Hose
06. T-Connector
07. Mounting Screws and Anchors
08. Escutcheon
09. Cartridge
10. Cartridge Locking Nut
11. Dome Cap
12. Cap, Setscrew and Hex Wrench
13. Handle
14. Diveter Cartridge
15. Hand Shower Connector Assembly
16. Setscrew

