

Description	PART #
*KETTLE	110401
TOP W DECALS	514464
GLASS FRONT (Tinted)	514371
Size (14.38" X 17" X .125")	
Size (365mm X 432mm X3.2mm)	
EXTRUSION-FRONT-UPRIGHT-need 2 per glass	18169
EXTRUSION-FRONT-BASE-need 1 per glass	18167
FRONT POPCORN DECAL	14218
GLASS SIDE (Tinted)	514376
Size (12.38" X 17" X .125")	
Size (314mm X 432mm X 3.2mm)	
EXTRUSION-SIDE-UPRIGHT-need 2 per glass	18169
EXTRUSION-SIDE-BASE-need 1 per glass	18168
SIDE POPCORN DECAL	14216
CHASSIE LABEL	14215
DOOR (13 1/16" X 13 1/16") (Tinted)	514196
HINGE SET	512166
DRAWER-OLD MAID	518816
DROP DOOR	514136
CLEAN OUT TRAY	514336
FEET FOR BASE (4)	540322
*POWER CORD	512092
*ELEMENT/WARMER	512078
*ELEMENT/KETTLE	514160
*GEAR MOTOR	512096
*SWITCH SET (2)	581140
MAGNET	512100
SOCKET/KETTLE	514038
SOCKET/LAMP	512155
KETTLE HANDLE ASSE.	512184
SPRING ONLY FOR KETTLE HANDLE	12038
KETTLE/LID HANDLE	512158
KETTLE LID ASSE.	514040
BULB (50 Watt Flood Light)	512161
HANGER-LEFT	512124
HANGER-RIGHT	512128

STIRRER	514056
THERMOSTAT	512139
PIN&CLIP KETTLE HI	512188
PIGTAIL	514101
BLACK ENDCAPS (Set of 4)	512107
OPERATING INSTRUCTION DOOR DECA	14107

*For use in Domestic (120v) models only

Export Parts (Part #1204220)

KETTLE	120401
POWER CORD	512012
GEAR MOTOR	512095
KETTLE ELEMENT	514165
SWITCH SET (2)	514100
WARMER ELEMENT	512079