

Use and Care

- For use under washer or dryer, domestic or commercial tools, pumps, generators etc to reduce noise and vibration
- Clean with mild soap and water