




Instruction Manual



Ax2pcs




Bx1pcs



Cx2pcs



Dx2pcs




Ex1pcs



Fx2pcs



Gx4pcs




Ix1pcs




Hx32pcs

①



②



③

