




Replacement Parts List

Fairway 2 Handle Kitchen with Side Spray

MODEL	Internet SKU #	FINISH
HD67568-1101	301879684	Chrome



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Index	RP8037301		
2	Index	RP8037401		
3	Screw	RP50154		
4	Handle	RP1330401		
5	Inverter	RP64044	206671349	
6	Bonnet nut	RP70435	206864739	
7	Washer	RP64124		
8	Cartridge H	RP20067	301158139	
9	Cartridge C	RP20068	301158129	
10	Gasket	RP70488		

Part	Description	Part #	Internet SKU #	Store SKU #
11	Mounting nut	RP56001	203193994	579276
12	Aerator	RP3012401		
13	O-ring	RP60008		
14	Wearable ring	RP70077		
15	Clip	RP70023		
16	Diverter	RP70007		
17	Block	RP70421		
18	O-ring	RP60002		
19	Side spray	RP3606901		