


## **USE AND CARE GUIDE**

### BEACON PARK STEEL WOVEN ROCKING CHAIR



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

#### THANK YOU

### **Table of Contents**

Table of Contents	2
Safety Information	2
Product Caution	2
Safety Warnings	2
Warranty	2
What is Covered	2
What is Not Covered	2

Pre-Assembly	3
Planning Assembly	
Hardware Included	
Package Contents	4
Assembly	5
Care and Cleaning	9

## **Safety Information**

#### PRODUCT CAUTION

This chair was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this chair when any formidable / severe weather is approaching. Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

#### **SAFETY WARNINGS**



WARNING: Please keep children out of the assembly area before assembly.



WARNING: Weight limit for chair is 250 lbs (113.39 Kg) for each seat.



**WARNING:** This chair unit is heavy, and may require two adults for safe assembly.



**CAUTION:** Do not locate the product near any heat source.

### Warranty

### 2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

#### WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com

## **Pre-Assembly**

### **PLANNING ASSEMBLY**

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



**NOTE:** More than one person may be required to assemble this product.

### **HARDWARE INCLUDED**



**NOTE:** Hardware not shown to actual size.








Part	Description	Quantity
AA	M6x20 combination bolt	6+1
BB	M6x50 combination bolt	4+1
CC	Hex wrench	1

### **PACKAGE CONTENTS**




Part	Description	Quantity
Α	Right arm	1
В	Left arm	1
С	Seat	1
D	Backrest	1
E	Back cushion	1
F	Seat cushion	1

## **Assembly**


# 1 CONNECTING THE RIGHT ARM TO THE SEAT

- □ Place the right arm (A) on a soft surface.
- Align the holes on the right panel of the seat (C) to the holes on the front of the right arm (A), and secure by M6x20 combination bolts (AA) using the hex wrench (CC).
- □ Do not fully tighten all bolts at this step.




# **2** ATTACHING THE BACKREST TO THE SEAT AND THE RIGHT ARM

- □ Attach the backrest (D) to the seat (C) and the right arm (A), using an M6x20 combination bolts (AA) and M6x50 combination bolts (BB).
- □ Do not fully tighten all bolts at this step.




# 3 CONNECTING THE LEFT ARM TO THE SEAT AND THE BACKREST

- □ Connect the left arm (B) to the seat (C) and the backrest (D) using M6x20 combination bolts (AA).
- Do not fully tighten all bolts at this step.




# 4 CONNECTING THE ARMS TO THE BACKREST

- Turn the chair right side up.
- □ Connect the back of the right and the left arm (A & B) to the backrest (D) by using M6x50 combination bolts (BB).
- Do not tighten all the bolts at this step.



# 5 TIGHTENING THE BOLTS

- Once all of the bolts are in place, fully tighten the bolts using the hex wrench (CC).
- □ Turn the chair right side up.
- Place the seat and the back cushion (F&E) on the chair.
- Ensure all connections are secure before use.



## **Care and Cleaning**

- For best results, clean the chair with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the chair in a dry, sheltered place when not in use.
- □ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

### 1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

Retain this manual for future use.