






# HOME DECORATORS COLLECTION

## ASSEMBLY INSTRUCTIONS FOR SKU NO. 1002964499, 1002964500, 1002964467, 1002964468, 1002964491 & 1002964492 ALDRIDGE CONSOLE TABLE


<p>(A)</p>  <p>TOP 1 Pcs</p>	<p>(E)</p>  <p>ALLEN BOLT 8 X 60 MM 12 Pcs</p>	<p>(F)</p>  <p>WASHER 8 X 22 MM 14 Pcs</p>	<p>(G)</p>  <p>ALLEN KEY 6 MM 1 Pcs</p>		
<p>(B)</p>  <p>LEG 2 Pcs</p>	<p>(C)</p>  <p>BOTTOM BASE 2 Pcs</p>	<p>(D)</p>  <p>BOTTOM SUPPORT 1 Pcs</p>	<p>(H)</p>  <p>PEN HEAD ALLEN BOLT 6 X 20 MM 4 Pcs</p>	<p>(I)</p>  <p>WASHER 8 X 17 MM 4 Pcs</p>	<p>(J)</p>  <p>METAL L-ANGLE 50 X 25 X 25 MM 4 Pcs</p>
			<p>(K)</p>  <p>SCREW 6 X 32 MM 8 Pcs</p>	<p>(L)</p>  <p>ALLEN BOLT 8 X 40 MM 2 Pcs</p>	<p>(M)</p>  <p>ALLEN KEY 4 MM 1 Pcs</p>

### CARE INSTRUCTIONS


Hardware may loosen overtime. Periodically check that all connections are tight. Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners. All hot serving dishes should be placed on a pad. Any liquid spilled onto the furniture should be cleaned up immediately with a damp cloth.




Step -01 Place the table top (A) upside down on a clean surface.



Step -02 Align the holes in the leg (B) and frame of top (A). Using the allen key (G), tighten the washers (F) and allen bolts (E).




Step- 03 Use allen key (M) to tighten the metal angle (J) with pen head allen bolt (H) and washer (I). Do not fully tighten. Use a screw driver to tighten metal angle (J) to the leg (B) with wooden screw (K). Once completed, tighten allen bolt (H) fully.




Step -04 Tighten the second leg (B) on other side in the same manner as mentioned in step - 02 & 03.


Note : Please wait until the table is fully assembled prior to fully tightening bolts.



Step -05 Place the base (C) on the leg (B) and secure with allen bolt (E) and washer (F) with allen key (G).



Step -06 Affix the bottom support (D) to leg bases by tightening allen bolts (L) and washers (F) with allen key (G).



Step -07 Turn the coffee table upright. It is now ready for use.