



## Instructions

Tools Required: Screwdriver, Adjustable Wrench

1. Turn off water supply.
2. Remove handle screw (A) and pull off handle (B).
3. Unscrew bonnet (C) and pull out stem (D).
4. Insert new seat (E) into faucet body.
5. Insert new stem into faucet body.
6. Replace bonnet (C) and tighten.
7. Place handle (B) on stem and tighten with screw (A).