



Parts List for DCBL720B Type 1

Item Number	Part Number	Description	Qty Required
1	90613988	HOUSING ASSEMBLY	1
2	90614957	HOUSING ASSEMBLY	1
3	90625669	MOTOR ASSEMBLY	1
4	90616020	CONTROL MODULE ASSY	1
7	90620291	HEAT SHRINK SLEEVE	1
11	90615033	INLET CAP	1
12	90614111	HOUSING	1
13	90605734	ACTUATOR	1
14	90605686	ACTUATOR	1
15	90608646	WASHER	1
16	90611827	SCREW	1
17	330021-00	NUT,ELASTIC STP	1
18	90605688	CLUTCH SPRING	1
19	90605685	TRIGGER	1
20	90614091	PIN	1
21	90605748	TUBE CLIP	1
22	90609997	TORSION SPRING	1
23	90605114	SWITCH SUPPORT	1
24	90611771	WIRE CLIP	1
25	330019-28	SCREW PLASTITE	1
26	330019-03	SCREW,PLASTITE	14
27	90617442	SCREW,PLASTITE	3
29	90620643	FOAM PAD	2
40	90622640	BLOWER TUBE	1
150	90617973	RATING LABEL	1
151	90617971	IDENT LABEL	2
866	DCB205	BATTERY PACK	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for DCBL720B Type 1

Item Number	Part Number	Description	Qty Required
871	DCB115	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.