

# MERRIN / WESTVILLE / BEAUFORT

---

## EURO RECLINER MODEL # AXCEUREC-03





**FOR REPLACEMENT PARTS OR HELP WITH  
ASSEMBLY PLEASE CONTACT US AT:**

**[simpli-home.com/customer-support](https://simpli-home.com/customer-support)**

**PLEASE ENSURE TO HAVE THE MODEL #  
FROM THE PACKAGING OR INSTRUCTION BOOKLET**

**TO RETURN THE PRODUCT:  
PLEASE CONTACT THE RETAILER  
WHERE THE ITEM WAS PURCHASED FROM**



**ENTER  
TO WIN**

**Upload an image of our furniture  
in your home with a short review  
to our facebook page for a chance to**

**Win up to \$3000 of  
Simpli Home furniture!!!**

[www.facebook.com/simplihomefurnishings](http://www.facebook.com/simplihomefurnishings)



**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

## **SAFETY INFORMATION**

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

**WARNING:** This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets.

We recommend that you assemble this unit on a carpeted floor to avoid scratches. We do not recommend the use of power tools for assembly as this could damage the unit. Only use manual tools.

**Requires 2 people for ease of assembly.**

## **CARE and MAINTENANCE**

Wipe regularly with clean water and a damp, clean, soft white cloth.

General cleaning can be done as needed with a mild detergent and water solution. Always rinse with clean water and dry.

For heavy soiling, dampen a soft white cloth or soft bristle brush. Use care as scrubbing can damage the surface.

More difficult stains can be treated, but this should be occasional, not daily, cleaning.

ANY cleaning solution used must be removed with clean water and a clean white cloth. Cleaning residue left on the material can cause it to dry out and crack, or affect the color.

**DO NOT** use any cleaners with corrosive ingredients (lye, acids or ammonia).

# PRE-ASSEMBLY INFORMATION

## PARTS DESCRIPTION

1



CHAIR  
QTY 1

2




CHAIR BASE  
QTY 1

3




ARMREST  
(RIGHT and LEFT)  
QTY 1

4




OTTOMAN CUSHION  
QTY 1

5



U-BOARD  
QTY 1

6



OTTOMAN BASE  
QTY 1

**NEED HELP?** For help with assembly or if you are missing a part,  
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 4 pm EST)

# PRE-ASSEMBLY INFORMATION

## HARDWARE DESCRIPTION

**A**




ALLEN KEY SCREW  
M6 X 18 mm  
QTY 8

**B**



CONNECTOR PINS and NUTS  
M8 X 25 mm  
QTY 2

**C**



ALLEN KEY SCREW  
M8 X 35 mm  
QTY 4

**D**




ALLEN KEY SCREW  
M8 X 60 mm  
QTY 2

**E**



SMALL WASHERS  
QTY 4

**F**



LARGE WASHERS  
QTY 4

**G**



M6 ALLEN KEY  
QTY 1

**H**



M8 ALLEN KEY  
QTY 1

**I**




WRENCH  
13mm  
QTY 1

**NEED HELP?** For help with assembly or if you are missing a part,  
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 4 pm EST)

# ASSEMBLY


## STEP 1



Align the Chair (1) to the Chair Base (2).  
Use Screws (D) to attach to the Chair Base (2).  
Use M8 Allen Key (H) to tighten.

# ASSEMBLY

## STEP 2



Secure Chair (1) to the Chair Base (2) with Connector Pins and Nuts (B).

Use M6 Allen Key (G) and Wrench (I) to tighten.

# ASSEMBLY

## STEP 3




Attach left and right Armrests (3) to the Chair Base (2) with Screws (A).

Use M6 Allen Key (G) to tighten.

# ASSEMBLY

## STEP 4




### OTTOMAN ASSEMBLY

Attach Ottoman Base (6) to the U-board (5) with Screws (C) and Large Washers (F).

Use M6 Allen Key (G) to tighten.

# ASSEMBLY

## STEP 5




### OTTOMAN ASSEMBLY

Attach Ottoman Cushion (4) to brackets on the U-Board (5) using Screws (A) and Small Washers (E).  
Use M6 Allen Key (G) to tighten.

# ASSEMBLY

## TO ADJUST TILT FUNCTION



While seated, reach underneath the right side of the recliner and turn the handle. The recliner will tilt backward when you rotate the handle. Rotate the handle until the desired angle is reached.



## WARRANTY

Thank you for purchasing a **Simpli Home – Wyndenhall – Brooklyn + Max** product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line at 1-866-518-0120 ext. 262 from 9 am to 4 pm, Monday to Friday, Eastern Standard Time or by email at [customerservice@simpli-home.com](mailto:customerservice@simpli-home.com).

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.



**Question, problems, missing parts?**

**Before returning your product**

please email Customer Support at

**[customerservice@simpli-home.com](mailto:customerservice@simpli-home.com)**

or call

Customer Service at 1-866-518-0120 ext. 262

Monday to Friday between 9 am – 4 pm EST

For more information visit us on our website

**[www.simpli-home.com](http://www.simpli-home.com)**

Like us on facebook

**[www.facebook.com/simplihomefurnishings](http://www.facebook.com/simplihomefurnishings)**