

INSTRUCTION SHEET CARE AND USE

THE **3 IN 1 Repair Stick** is a quick and simple way to repair scratches, nicks, dents or other minor imperfections in any wood surface. It is ideal for touching up furniture, cabinets, trim, doors, floors and more. You can blend different colors to create your own custom color. The Mohawk marker is formulated with stain and finish so your wood project can be repaired and protected in one easy step.

Marker Directions:

- 1. Shake well before using.
- 2. Remove cap and relieve pressure by depressing nib / tip in an upright position. To start flow, press pen and nib down until wet. Test color in an inconspicuous area to ensure the color you have chosen will match your project.
- 3. Press pen down and apply stain to wood. Wipe off excess using a soft, lint free cloth.
- 4. Replace cap tightly after each use.

Fill Stick Directions:

- 1. Prior to repairs, determine the color that best matches your project. Test color in an inconspicuous area to ensure the color you have chosen matches your project.
- 2. Work / Rub the Fill Stick into the defect until completely filled.
- 3. Remove the excess material with the Leveler cap.



DANGER

Hazards: Highly flammable liquid and vapor. May cause cancer. May cause damage to organs through prolonged or repeated exposure. May be fatal if swallowed and enters airways. Causes skin irritation*.

PRECAUTIONS PREVENTION: KEEP OUT OF REACH OF CHILDREN

Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Keep container tightly closed. Obtain special instructions before use. Use personal protective equipment as required. Do not breath dust, fume, gas, mist, vapors, spray. Wear protective gloves, protective clothing, eye protection, face protection. FIRST AID: If exposed or concerned, Get medical advice/attention. Get medical advice/attention if you feel unwell. IF SWALLOWED, Immediately call a POISON CENTER or doctor/physician. Do NOT induce vomiting. IF ON SKIN, Wash with plenty of soap and water. Take off contaminated clothing.

See Safety Data Sheet (SDS) for more information.

CONTENTS: ethanol, pm acetate, toluene, polyketone resin, resin solids, carbon black, isopropanol, petroleum distillate.

WARNING: Cancer and Reproductive Harm - www.P65Warning.ca.gov

* Fill Stick is non-hazardous with proper use.