

Drip Drop Installation

The Drip Drop Globes can simply be filled with water and inserted into the soil in your potted plant. It will slowly release water over time to ensure your plants continue to receive water.