

PARTS LIST AND ASSEMBLY DIAGRAM

Part	Description	Qty.
1	Bolt	2
2	Nut	2
3	Retaining Ring	2
4	Hinge Axle	1
5	Hook	1
6	Adjustment Bolt	1
7	Hook	1
8	Axle Pin	6
9	Hook	1

Part	Description	Qty.
10	Threaded Axle	1
11	Hook	1
12	Spring	2
13	Plain Axle	1
14	Nut	2
15	Holding Pin	4
16	Pin Ring	4
17	Safety Ring	1
18	Compression Spacer	1

