

E-Commerce by Enitial Lab

# ASSEMBLY INSTRUCTIONS

### MODEL # FGI-18604C21-L

#### **Questions?**

GIVE US A CALL: 1-888-980-5122 MON – FRI 8:30AM – 5:30PM (PST)

#### **TOOLS REQUIRED**



(Not Included)



Philips Screwdriver



2 - Persons Recommended



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



VERSION # 19-01-15






Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.




# PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.


















#### Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.

#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.

#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

## ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Save the instructions and store any supplied tools for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

# CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


#### Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.










Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.


cam bolt

cam lock





Insert the cam bolt into the bolt hole of joint panel.




Turn the cam lock clockwise gently until it will not turn any more.


### **Drawer Cabinet**

#### FGI-18604C21-L

- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.





#### PARTS A1PC **B**1PC **●**1PC **B**2PC ●4PCS 0 **D**2PCS **G**1PC 6PCS **K**6PCS **6**PCS 6PCS **O**6PCS ---. M1PC **1**PC





	ACCESSORIES						
A1 12PCS	(A2)12PCS	A3)2PCS					
	0.78"						
(A4)1PC	A5)1PC 1.26"	(A6)1PC	(A7)1PC	(A8) 2PCS 0.47" ())))))))))))))))))))))))))))))))))))			
A9 1PC							
Q							

GET READY Please group boards as below.							
●6PCS	<b>(</b> 6PCS	●6PCS	6PCS	Cepcs	Drawer		
₿1PC	<b>0</b> 4PCS	<b>@</b> 2PCS	©2PCS	C 1PC			
<b>()</b> 1F	ос С	<b>©</b> 1PC		▲1PC	Body		













7 Part () x1PC Hardware (2) x 3PCS









12

### ASSEMBLY COMPLETED



Frease ensure the furniture rests on an even and flat surface. If the product wobbles or feels oose, double-check all oolts and/or screws are properly tightened and secured.

### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




#### Wall Mounting and Fixing



#### **EXPANSION WALL ANCHOR**

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. liability for product damage or failure due to using the incorrect anchors will fall on the installer.

MAINTENANCE




#### CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

We recommend a yearly check to see if the wall anchor or

screw has loosened. If so, please remove the existing wall

anchor and screw, and use a new anchor.



15 / 15

/early

Checl