

Assembly & Installation Instructions

ITEM NO.: 31171F-SG

CAUTION:

Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

WARNING

Wires and cables are all attached (further wiring is not needed from consumer). When unpacking product, be careful to not pull wires as it may result as a bad connection. Do not plug into electrical outlet until lamp is fully assembled.

ASSEMBLY INSTRUCTIONS:

Unpack and place all parts on a surface or floor.

1. Assemble stems (A) to stems (B)
2. Assemble legs (A/B) to lamp base (C).
3. Gently pull the cord (I) so that the neck (D) comes into contact with the body (C) .
4. Screw the neck (D) onto the lamp body (C), and straighten the cord (I) .
5. Insert the harp (E) into the neck .
6. Place the shade (F) on the harp (E) and secure shade with finial (G).
7. Loosen then tighten (H) to adjust the lamp height.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug(one blade is wider than the other), as a feature to reduce the risk of electric shock, this plug will fit in a polarized outlet only one way, if the plug does not fit fully in the outlet, reverse the plug. if it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

CLEANING:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish.

Note:

Turn the power off (unplug from the wall outlet) before replacing the bulb. Make sure the bulb has sufficient time to cool down.

