

Use and Safety

Safety During Use:

- Keep a working fire extinguishing canister (**sold separately**) that has not passed its expiration date on hand to extinguish a fire in the event it is needed.
- Never use this product to build a fire in an enclosed area.
- Do not move the Fire Vessel once a fire is ignited.
- Never leave a burning fire unattended.
- Keep children and pets away from this product.
- Do not attempt to cook food using this product.
- The fire bowl surface will be hot enough to cause serious burns, do not touch these surfaces during use and after a fire has been recently extinguished.
- Do not use alcohol, ethanol, spirits, gasoline, kerosene, or any other highly flammable fluid to ignite or reignite the fire in this product
- Use a metal scoop or shovel to cover the fire and coals with sand to smother and extinguish the flames when you are done using this product.
- We do not recommend using water to attempt to extinguish an active fire. If you do, leaving a wet base in the fire vessel will void your product warranty.

Safety After Use:


- Wait until the fire has been extinguished for at least an hour before attempting to touch the products surfaces or clean the fire bowl.
- Empty most of the base contents of the fire bowl after use. It is recommended to leave a thin layer of dry sand and ash in the bottom of the bowl, emptying the rest of the sand and ash for subsequent use by placing it into a separate container for storage in a cool dry place.
- Place the unused fire vessel for storage in a cool dry place, or use a protective cover (**sold separately**) to prevent damage caused by exposure to the elements outdoors.

Fire Vessels

by **astella**
Indoor | Outdoor | Accessories

Midas Fire Pedestal

FP204



Safety and Instructions