

## Operating Instructions for the Vulcan, 770-00-175

- 1. Remove BBQ grill and all components from the storage bag. Make sure to remove all cardboard and/or plastic from all parts before using the grill.
- 2. Unfold the legs (away from the center) and place the grill on a secured and level surface. Place the grate on top of the BBQ grill.
- 3. Locate the locknut on the side of the BBQ grill. Align the BBQ screw post of the regulator with the locknut of the grill. Turn the locknut clockwise until the propane regulator is secured. Do not over tighten as this may cause damage to the screw post. A small wrench may be used, but is not necessary to form a proper connection. (Wrench not included.)
- 4. Attach a propane (LP) gas tank to the grill according to the manufacturer's directions printed on the canister. Be sure to follow manufacturer's directions for use to avoid injury. The grill is now ready to light.
- 5. How to light Using a BBQ lighter or fireplace matches, insert flame through an open exterior hole at the bottom of grill so flame reaches into the grill's interior. Turn knob to "on" position; BBQ should ignite immediately, at which point one should remove the flame source. If BBQ does not ignite within 2 seconds, turn knob "off", wait 20 seconds and repeat previous steps.
  ALWAYS BE SURE TO INTRODUCE FLAME SOURCE BEFORE TURNING GAS KNOB TO "ON" POSITION. Turning gas knob on before lighting the grill may likely result in gas building up in the gas line which could cause serious injury when BBQ is lit.

## **Instructions for Storing the Vulcan**

- 1. Once the BBQ grill has fully cooled, remove the grate from the BBQ and put aside. Unscrew the regulator from the BBQ grill, and place it under the heat plate at one end. Invert the lid so that it rests inside the grill, making sure the handle fits into the cut-out section of the heat plate.
- 2. Fold the legs of the grill in (towards the center), making the BBQ grill as compact as possible. Place the BBQ grill in the bottom of the storage bag. Place the BBQ grill in the bag on top of the grate. Cinch the drawstring to close the bag. Place the bag in the bottom-most zippered compartment of the Vulcan.