

ACOUSTICAL PANEL

Sound Control with Style

Parts Included with Panel:

Tools You May Need For Your Project:

- Angled Impaling Clips (use two per panel)
- Anchor Screws



Tape Measure





#2 Phillips Screwdriver

Level

Paintable



INSTALLATION INSTRUCTIONS:

1. PAINT



It is recommended to use canned spray paint designed for fabric or vinyl application. Follow the application directions provided by the spray paint manufacturer. Allow to fully dry before installing the product. Different paint types and application methods may affect the acoustic performance of the product. See Product Data Sheet for additional information.







Determine the placement of the panel on the wall. Use painters tape to mark the wall where hanging clips (included) should go. Ensure hanging clips (included) should go. Ensure hanging clip placements are at least three inches away from the edges of the panel.



3. HARDWARE




Use a level or laser tool to ensure that the hanging clips are level so that the panel will engage all hanging clips evenly. Once hardware is level, attach hanging clips using the included screws and a screwdriver.



4. MOUNTING



Position panel 5/8 inch above placement position so that it is lightly touching the points of the hanging clips. With your hands placed on the panel face, push the panel down toward the wall until it is seated on the hanging clips.



5. LEVEL



Position a wooden block on edge of panel and use a hammer to lightly tap for adjustment. If panel must be adjusted up, remove and re-seat panel on clips, do not tap upwards. Inspect the edges on the panel where it meets the wall. The gap should be consistent around the entire perimeter of the panel.