




Replacement Parts List

Modern Single-Hole Touchless Bathroom Faucet

INTERNET#	MODEL	SKU #	FINISH
311893465	HD67688W-6010H	1004929183	Matte Black



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Handle assembly	RP1370810H		
2	Bonnet nut	RP70539		
3	Cartridge & Screw	RP20117		
4	Aerator	RP30209		
5	Escutcheon	RP8052710H		
6	Gasket	RP80528		
7	Block	RP70421		
8	O-ring	RP60002		
9	O-ring	RP60131		

Part	Description	Part #	Internet SKU #	Store SKU #
10	Quick connect assembly	RP70683		
11	Washer	RP64131		
12	Washer	RP64146		
13	Nut & Screw	RP56119		
14	Sensor control box	RP70720		
15	Battery pack	RP70707		
16	Press pop-up assembly	RP4026910H		