


Open the carton and place all the parts onto a clean, non-marring surface. Put Bottom Tray(A) facedown.

Turn Wheels(E) fully into the two mounting positions using Wrench(④) as shown in the picture above.


The Trolley parts are heavy, always have a second adult to assist you whenever lifting or moving them.




2.1) Align Bottom Tray(A) to the Back Frame(C).

2.2) Attach Bottom Tray(A) to Back Frame(C) using Bolts(②) with Allen Key(③) as shown in the picture above.

Do not fully tighten the Bolts.





Now in a sequential manner, proceed to tighten all Bolts at all joints.

Note: DO NOT fully tighten a BOLT in one go and then move on to the next. Rather, in a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured. This methodology will ensure maximum evenness once all Bolts are fully tightened.

Your Trolley is ready for use.

This Trolley can only be used on a flat, level surface.

Care & Maintenance
Do not put hot items directly on furniture surface
Do not clean furniture with harsh cleansers or polish.
To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.
Children should not climb or jump on the furniture.
Do not write on furniture without a padded barrier to protect the surface.
To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
Not for commercial use. For residential use only .
Stains may be removed with mild soap solution and damp cloth.
Dust and pick-up spills using a clean, non-colored, lint-free cloth .
What is Proposition 65?
Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list
include wood dust, brass, and other everyday substances, which can be found in very common household
items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and
furniture.
Why Did I Find a Proposition 65 Warning on My Home Goods Product?
We include Proposition 65 warnings on all of our products because there is always a chance that one of the
800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.
Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

