



How to choose the right BRISA Retractable Screen Door

Easy Installation


1 Determine your door type.



SINGLE DOOR



DOUBLE DOORS




SLIDING DOORS

*Please refer to Brisa Product Selection Matrix to confirm the model that will work for your door

2 Measure your door height.

Measure your door from top to bottom. This will determine which size retractable screen door fits your application.



Height: _____ , _____ ”

3 Choose your retractable screen door model. *(Most Doors are Standard Height)

Brisa Product Selection Matrix					
Door Type*	Door Height	Fits Door Width**	Screen Size	Colors Available	Model
Single	6'6" (78")	32" to 36" width	Short	White	BRSHWE
				Bronze	BRSHBE
				Sandstone	BRSHAE
	6'8" (80")	32" to 36" width	Standard	White	BRSTWE
				Bronze	BRSTBE
				Sandstone	BRSTAE
8'0" (96")	32" to 36" width	Tall	White	BRTLWE	
			Bronze	BRTLBE	
			Sandstone	BRTLAE	
Double	6'6" (78")	68" to 72" width	Short	White	BRDDSHWE
				Bronze	BRDDSHBE
				Sandstone	BRDDSHAE
	6'8" (80")	68" to 72" width	Standard	White	BRDDSTWE
				Bronze	BRDDSTBE
				Sandstone	BRDDSTAE
	8'0" (96")	68" to 72" width	Tall	White	BRDDTWE
				Bronze	BRDDTBE
				Sandstone	BRDDTAE
Sliding	6'8" (80")	32" to 36" width	Standard	White	BRSLWE

* Models work for in-swing and out-swing doors
 ** Single doors less than 32" W, and double doors less than 68" W, require two simple cuts.

How to install.



Easy 30-Minute Average Installation


Brisa has only five parts and requires a single tool (powerdrill/screwdriver) for installation. Brisa adjusts quickly for 32"-36" single doors and 68"-72" double doors, with no metal cutting required.

Single doors less than 32" W, and double doors less than 68" W, require two simple cuts.


See installation manual for details.

Three Step Installation

1 Assemble 5 Parts



2 Place Screen Onto Door Frame



3 Secure Screen Onto Door Frame

