

Cycle Guide

■ = default setting

○ = allowable option

| Cycle | Fabric Type | Dry Level | Temperature | Time | More Time/ Less Time | Wrinkle Care | Turbo Steam | Damp Dry Signal | Energy Saver |
|-----------------|--|------------|-------------|------------|-------------------------|--------------|-------------|-----------------|--------------|
| Steam Fresh™ | comforters, shirts, trousers (except especially delicate fabrics) | Off | Mid High | 10 | ○ | ○ | ○ | | |
| | | | Adjustable | Adjustable | | | | | |
| Steam Sanitary™ | comforters, bedding, children's clothing | Off | High | 31 | | ○ | ○ | | |
| Anti Bacterial | Do not use this cycle with delicate fabrics. | Very | High | 1:10 | | ○ | | | |
| LowTemp Dry | Only normal / towels fabric type (Max 3lb) | Normal | High | 50 | | ○ | | | |
| | | Adjustable | | | | | | | |
| Bedding | comforters, pillows, shirts | Normal | Medium | 55 | | | | | |
| | | Adjustable | | | | | | | |
| Heavy Duty | jeans, heavyweight items | Adjustable | High | 54 | | ○ | ○ | ○ | |
| Normal | work clothes, corduroys, etc. | Normal | Medium | 41 | | ○ | ○ | ○ | ○ |
| | | Adjustable | | | | | | | |
| Jumbo Dry | comforters, pillows, shirt | Normal | Medium | 1:25 | | ○ | | | |
| | | Adjustable | | | | | | | |
| Perm. Press | permanent press, synthetic items | Normal | Low | 32 | | ○ | ○ | ○ | |
| | | Adjustable | | | | | | | |
| Delicates | lingerie, sheets, blouses | Normal | Low | 28 | | ○ | | ○ | |
| | | Adjustable | | | | | | | |
| Towels | denim, towels, heavy cottons | Normal | Mid High | 55 | | ○ | | ○ | |
| | | Adjustable | | | | | | | |
| Speed Dry | For small loads with short drying times | Off | High | 25 | ○ | ○ | | | |
| | | | Adjustable | Adjustable | | | | | |
| Air Dry | For items that require heat-free drying such as plastics or rubber | Off | Off | 30 | ○ | ○ | | | |
| | | | | Adjustable | | | | | |

Sensor Dry Cycles

Sensor Dry cycles utilize LG's unique dual sensor system to detect and compare the moisture level in clothes and in the air and adjust the drying time as needed to ensure superior results. The dryer automatically sets the dryness level and temperature at the recommended setting for each cycle. The estimated time remaining will be shown in the display.

LowTemp Dry

This cycle can save energy over the Normal cycle, depending on the load size. It may be necessary to adjust the Dryness Level to achieve the desired amount of drying.

NOTE

To protect your garments not every dryness level, temperature, or option is available with every cycle. See the Cycle Guide for details.

Manual Dry Cycles

Use Manual Dry cycles to select a specific amount of drying time and a drying temperature. When a Manual Dry cycle is selected, the ESTIMATED TIME REMAINING display shows the actual time remaining in your cycle. You can change the actual time in the cycle by pressing MORE TIME or LESS TIME.

NSF CERTIFIED BY NSF/P154

NSF International (formerly the National Sanitation Foundation), certifies that the **Anti Bacterial** cycle reduces 99.9% of bacteria on laundry, and none of the bacteria will carry over onto the next laundry load.

- The default settings for the **Anti Bacterial** cycle are **High** temperature and **Very Dry**. These default settings cannot be changed.
- Do NOT use this cycle with delicate items or fabrics.