



Models/Modelos/Modèles
 P6919LF
 Series/Series/Seria


RP93988▲
 Set Screw & Handle
 Tornillo de Presión y Manija
 Vis de calage et Manette




RP93990▲-1.5
 Wand, Hose Assembly
 Cabeza del Rociador y Ensamble de la manguera
 Bec-douchette et Tuyau souple



RP93989▲
 Bonnet Nut & Cap
 Bonete y Casquete
 Chapeau et Embase



RP63206
 Cartridge Assembly
 Ensamble del Cartucho
 Cartouche




▲ Specify Finish
 Especificque el Acabado
 Précisez le Fini



RP100111
 Weight Assembly
 Ensamble de la Pesa
 Poids



RP93991▲
 (sold separately/Se vende por separado/
 Vendu séparément)
 Escutcheon, Baseplate & Mounting Nuts
 Chapa, Placa y Tuercas
 Plaque de finition, Plaque et écrous



RP70251
 Gasket (1), Washer (1),
 Nut (1) & Screws (2)
 Empaque (1), Arandela (1),
 Tuerca (1) y Tornillos (2)
 Joint (1), Rondelle (1),
 Écrou (1) et Vis (2)



RP93100▲
 (sold separately/Se vende por separado/
 Vendu séparément)
 Dispenser Assembly (complete)
 Ensamble del Surtidor (completo)
 Distributeur (complet)