

10x14 OASIS PERGOLA

MODEL: #1706521

DISCOVERY

Backyard Discovery 3305 Airport Drive Pittsburg, KS 66762 1-800-856-4445



- Owner's Manual
- Frequently Asked Questions
- Assembly Instructions
- Warranty Information

Register your new (Outdoor Product) on-line @ www.swingsetsonline.com (you will also find any updates on assembly instructions and information to order replacement parts)

Features the SAFE-T-FUSE fastening system.

Save this assembly manual for future reference in the event that you need to order replacement parts.



Missing A Part? CALL US BEFORE GOING BACK TO THE STORE!

The <u>store</u> where you made your purchase <u>does not stock parts</u> for this item.

If you have assembly questions or if you need parts, whether they are <u>missing</u> or <u>damaged</u>

Call Toll-Free Help Line or visit www.swingsetsonline.com

1-800-765-4138

PLEASE READ THIS BEFORE STARTING ASSEMBLY

- READ THE ASSEMBLY MANUAL COMPLETELY, PAYING SPECIAL ATTENTION TO THE IMPORTANT TIPS AND SAFETY INFORMATION.
- AFTER YOU HAVE READ THE ASSEMBLY MANUAL, YOU WILL BE ABLE TO DECIDE IF YOU NEED PROFESSIONAL HELP TO COMPLETE THE ASSEMBLY OF THE PLAYSET.
- SEPARATE AND IDENTIFY ALL PARTS TO MAKE SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
- IF YOU CAN'T FIND ALL OF THE PARTS, CHECK THE PACKING MATERIAL. SMALL PARTS MAY HAVE FALLEN INTO IT DURING SHIPMENT.
- IF YOU HAVE PROBLEMS WITH THE ASSEMBLY OR IF ANY PART IS MISSING OR DAMAGED, PLEASE CALL THE HELP LINE **1-800-765-4138** OR VISIT www.swingsetsonline.com.

PLEASE HAVE THE FOLLOWING INFORMATION WHEN YOU MAKE YOUR CALL:

- 1 MODEL NUMBER OF THE PRODUCT LOCATED ON THE FRONT OF THE ASSEMBLY MANUAL
- 2 DESRIPTION OF THE PART FROM THE PARTS LIST

Owner's Manual Outdoor Product

Dear Customer:

Please read entire booklet completely before beginning the assembly process.

Structures are not intended for public use. The Company does not warranty any of its residential structures subjected to commercial use such as: Recreational Park, or any similar Commercial Application.

Please follow all recommendations below. Failure to do so may result in the warranty being void and/or safety violations that could result in serious injury. This manual contains helpful information concerning Assembly Preparation, Installation Procedure, and Required Maintenance. Always keep safety in mind as your structure is being built.


PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. KEEP THEM IN A SAFE PLACE WHERE YOU CAN REFER TO THEM AS NEEDED. IN ORDER TO PROVIDE YOU WITH THE MOST EFFICIENT SERVICE, IT IS REQUIRED THAT YOU PROVIDE US WITH THE PART NUMBERS WHEN ORDERING PARTS.

For Your Records:

Please take time and fill out the information below. This information will be needed for warranty issues.

Where Purchased:
Date of Purchase:
Installation Date:
Installed by:

Installed



Tracking Number Reference Label

Tracking ID number on the carton and back of the ID plate are included for tracking purposes associated with warranty claims.

Owner's Manual Outdoor Product

Maintenance Instructions:

- 1. Check all nuts and bolts twice monthly during the usage season and tighten as required. (But not so tight that you crack the wood) It is particularly important that this procedure be followed at the beginning of each season.
- 2. Oil all metallic moving parts monthly during the usage period.
- 3. Check all coverings for bolts and sharp edges twice monthly during usage season to be certain they are in place. Replace when necessary. It is especially important to do this at the beginning of each new season.
- 4. For rusted areas on metallic members such as hinges, brackets, etc. sand and repaint, using a non lead-based paint meeting the requirements of Title 16 CRF Part 1303.
- 5. Inspect wood parts monthly. The grain of the wood sometimes will lift in the dry season causing splinters to appear. Light sanding may be necessary to maintain a safe environment. Treating your Product with protection (sealant) after sanding will help prevent severe checking/splitting and other weather damage.
- 6. We have applied a waterborne translucent stain to your unit. This is done for color only. Once or twice a year, depending on your climate conditions, you must apply some type of protection (sealant) to the wood of your unit. Prior to the application of sealant, lightly sand any "rough" spots on your set. Please note this is a requirement of your warranty.


Outdoor Product Assembly Manual FAQs:

- 1. Is the wood treated with chemicals? Backyard Discovery uses 100% Chinese Cedar wood which is naturally bug resistant, decay and rot resistant. To help ensure your families safety, our wood is completely chemical free and we do not use pressure-treated wood. The stain we use is a top coat using a water-based product that is for appearance only.
- 2. How often should the product be stained? Backyard Discovery recommends the product be stained once each year. A water or oil based stain can be used at the customer's discretion.
- 3. Why does it seem that my product is developing cracks? Wood is a natural material; no two pieces are exactly alike. Each piece has its own characteristics and personality and reacts differently to climate changes. When any wood product is exposed to the elements, it develops "wood checks". A check is the radial separation of the wood fibers running with the grain of the wood. These are caused by the varying temperature and moisture conditions. A check is not a crack it does not affect the strength or durability of the wood or structural integrity of the product.
- 4. Do Backyard Discovery products come with a warranty? Yes. All Backyard Discovery products carry a 1-year replacement warranty on all parts for manufacturer's defect. Our wood carries a 5 year warranty on rot and decay as well. Please see warranty details for more information.
- 5. What is the best way to get started assembling the product? Backyard Discovery recommends taking all the parts out of the boxes and arranging them by part number before you begin any assembly. This will not only allow faster assembly, but will also identify any parts that may be missing or damaged so they can be replaced before assembly. If parts are missing or need replacement, go to www.swingsetsonline.com/support.aspx and follow the prompts to order them. Next, read the assembly manual and get the tools ready for the job as recommended in the manual. If the assembly manual is lost or misplaced a new one can be printed from Backyard Discovery's website: www.swingsetsonline.com.
- 6. The 2"x4" boards do not measure 2"x 4". Why not? In the U.S. it's common practice to describe lumber dimensions using the rough cut sizes from the sawmill and not the finished dimensions. Retailers, home stores, etc. all use this accepted practice for describing lumber dimensions. However, Backyard Discovery products are designed and constructed using the actual dimensions so everything fits properly and remains so during the life of the product.

For more information and frequently asked questions, please refer to our website at www.swingsetsonline.com.


Tools Required for Installation:

(These are the tools that are generally required for assembly of our outdoor products. These tools are not included with the outdoor product purchase.)




Basic Setup Dimensions

Place the set on level ground, not less than 6 ft [2 m] from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.



GENERAL INFORMATION:

YOUR PERGOLA HAS BEEN DESIGNED AND ENGINEERED FOR RESIDENTIAL USE ONLY. A MAXIMUM WEIGHT LIMIT OF 600 POUNDS IS RECOMMENDED FOR THE BENCH.



Important Assembly Notes


- 1) While assembling unit, take time before and after each step to make sure unit is level. If unit is not level, assembly will be difficult and improper assembly may result. Extra care must be taken to ensure the unit is square.
- 2) Pay close attention to the ITEMS NEEDED FOR EACH STEP. They can be a valuable aid when sorting your wood and hardware. Assembly will be made easier if items are sorted by step.
- 3) Pay close attention to make sure you are using the correct hardware in the correct steps. Using incorrect hardware may result in improper assembly.
- 4) Whenever a T-nut is used, follow these directions. Place T-nut in pre-drilled hole. Tap in with hammer. Place bolt with washers in the opposite side. Hand tighten to make sure the bolt is in the T-nut. DO NOT over tighten.
- 5) Read any written steps of each step thoroughly. The written steps may include important information not shown in the illustrations.

Parts Identification Wood Components

(NOT TO SCALE)

| | | <u> </u> |
|-------------|--|----------|
| 0 | • | • |
| <u> </u> • | D1 - JOIST - W4L07567 | ٥ |
| | (2) 1 3/8"x5 1/4"x92 7/8" (36x134x2360) | |
| | • | |
| | • | |
| | D2 - JOIST END - W4L07575 (4) 1 3/8"x5 1/4"x37 1/2" (36x134x954) | |
| | | • 11 |
| " | | |
| | (8) D3 - SLOTTED JOIST - W4L07569 1 3/8"x5 1/4"x114" (36x134x2896) | |
| ۰ | 0 0 | • |
| Ü | (2) D4 - JOIST - W4L07568 | <u> </u> |
| | (2) 1 3/8"x5 1/4"x90" (36x134x2286) | |
| | | |
| | D5 - JOIST - W4L07570 | |
| | (2) 1 3/8"x5 1/4"x90" (36x134x2286) | |
| | ° | |
| | D6 - JOIST END - W4L07565 | |
| | (8) 1 3/8"x5 1/4"x15" (36x134x381) | |
| | | |
| | | |
| | D7 - JOIST END - W4L07566 (4) 1 3/8"x5 1/4"x37 1/2" (36x134x954) | |
| | () 1 3/0 33 1/4 337 1/2 (3031343334) | |
| | · · | |
| | DO LONG ANGLE PRACE WAL 07572 | |
| | D8 - LONG ANGLE BRACE - W4L07573 (8) 1 3/8"x5 1/4"x37 1/8" (36x134x942) | |
| | | |
| | · | |
| | D9 - SHORT ANGLE BRACE - W4L07574 1 3/8"x5 1/4"x29 3/4" (36x134x755) | |
| | Ţ | |
| | | |
| | (3) D10 - SUPPORT BOARD - W4L07560 1 3/8"x5 1/4"x14 1/8" (36x134x360) | |
| • | (| 0 |
| o | | 0 |
| | D11 - JOIST - W4L07716 (2) 1 3/8"x5 1/4"x92 7/8" (36x134x2360) | |
| · | | |
| | (C) G1 - SEAT - W4L07719 | |
| | (2) 1"x5 1/4"x92 7/8" (24x134x2360) | |
| | · · | |
| | [| |
| | (2) 1"x5 1/4"x39 1/2" (24x134x1002) | |


Parts Identification Wood Components (NOT TO SCALE) G3 - ARMREST - W4L07551 1"x5 1/4"x18" (24x134x458) G4 - ARMREST - W4L07552 1"x5 1/4"x18" (24x134x458) H2 - SUPPORT BOARD - W4L07558 1"x3 3/8"x16 1/8" (24x86x410) H3 - BRACE - W4L07717 H5 - BRACE - W4L07557 1"x3 3/8"x12 1/4" (24x86x312) 1"x3 3/8"x12 1/4" (24x86x312) H4 - BRACE - W4L07554 (3) 1"x3 3/8"x12 1/4" (24x86x312) г7 J1 - TABLE TOP RAIL - W4L07561 2"x3"x84 1/2" (50x76x2146) J2 - TABLE TOP RAIL - W4L07562 (4) 1"x3"x12 1/4" (24x76x310) J4 - SUPPORT BOARD - W4L07563 (2) 1"x2 3/8"x26 1/8" (24x60x662) J5 - SUPPORT BOARD - W4L07564 1"x2 1/8"x26 1/8" (24x54x662) J7 - SUPPORT BOARD - W4L07718




(12) **P2 - PURLIN - W4L07572** (12) **1** 3/8"x1 3/8"x90 1/4" (36x36x2291)

Parts Identification


Wood Components
(NOT TO SCALE)




(2) WA1 - WALL ASSEMBLY - W2A02102 2 7/8"x15"x39 1/2" (72x382x1003)




(1) WA2 - WALL ASSEMBLY - W2A02096 1"x16 3/4"x95 1/2" (24x424x2426)




(1) WP1 - PERGOLA POST - W2A02098 5 1/2"x5 1/2"x37 1/8" (140x140x943)



(1) WP2 - PERGOLA POST - W2A02097 5 1/2"x5 1/2"x37 1/8" (140x140x943)



(2) WP3 - PERGOLA POST - W2A02099 5 1/2"x5 1/2"x89 1/2" (140x140x2273)



(2) WP4 - PERGOLA POST - W2A02100 5 1/2"x5 1/2"x89 1/2" (140x140x2273)




(1) FP1 - POST CAP - W2A02101 1 7/8"x6 1/2"x6 1/2" (48x164x164)




(2) TT1 - TABLE TOP ASSEMBLY - W2A02104 1 5/8"x17 5/8"x27 7/8" (40x448x708)

Parts Identification Wood Components

(NOT TO SCALE)





(1) TT2 - TABLE TOP ASSEMBLY - W2A02105 1 5/8"x17 5/8"x27 7/8" (40x448x708)



(2) TT3 - TABLE TOP ASSEMBLY - W2A02103 1 5/8"x15 5/8"x27 7/8" (40x398x708)

Parts Identification Hardware





Parts Identification Hardware













(125)/R - WASHER LOCK EXT 8x19 BLK - H100198









Parts Identification Accessories

(NOT TO SCALE)



(6) HT - FOOT 142 SQUARE POST - A100029



(10) - 90° L-BRACKET - BLK - A4M00555





(1) SQ - "A" REVISION TAG - A100314






(1) STAIN MARKER - MED BRN-2UV - A6P00171










D5 - JOIST - W4L07570 (1) 1 3/8"x5 1/4"x90" (36x134x2286)


(2) WP4 - PERGOLA POST - W2A02100


5 1/2"x5 1/2"x89 1/2" (140x140x2273)













D3 - SLOTTED JOIST - W4L07569

(8) 1 3/8"x5 1/4"x114" (36x134x2896)






P2 - PURLIN - W4L07572 (12) 1 3/8"x1 3/8"x90 1/4" (36x36x2291)

(96) **SCREW PFH 8x2-1/2 BLK**

STEP 9






(4) HT - FOOT 142 SQUARE POST - A100029

STEP 10

DECIDE WHERE TO PLACE THE PERGOLA; GRASS, CONCRETE OR OTHER MATERIAL. PLACE THE PERGOLA EXACTLY WHERE IT WILL BE ANCHORED WHEN COMPLETED AND SLIDE A FOOT UNDER EACH POST.

NOTE:


IF NOT PLACING ON CONCRETE, PROCEED TO STEP 14.





SQUARE POSTS AND TIGHTEN ALL BOLTS AND SCREWS AT THIS TIME.

STEP 11
USE CHALK TO TRACE AROUND THE EDGES OF EACH FOOT.




STEP 12


MOVE THE PERGOLA ASIDE. PLACE EACH FOOT INSIDE OF THE LINES DRAWN IN THE PREVIOUS STEP. USING A 3/16" CONCRETE DRILL BIT, PILOT DRILL ATTACHMENT HOLES INTO THE CONCRETE PAD.

NEXT, USE THE 1/4"x2" CONCRETE ANCHORS TO ATTACH EACH FOOT TO THE CONCRETE SURFACE.






STEP 13
SET THE PERGOLA BACK IN PLACE, SETTING EACH POST INSIDE A FOOT.



STEP 14
ATTACH FEET TO EACH POST.






SCREW PWH




(1) XR - BYD ID TAG (SMALL) WITHOUT AGES - A100241

STEP 15

IF YOU CHOOSE NOT TO INSTALL THE SEAT OR BAR, YOUR PERGOLA IS NOW COMPLETE. OTHERWISE, CONTINUE TO NEXT STEP.








STEP 17

PLACE WALL/POST ASSEMBLY IN POSITION IN THE CENTER OF OUTER POSTS AS SHOWN.

USE CHALK AND TRACE AROUND FOOT (NOT NECESSARY IF NOT PLACING ON CONCRETE).




(2) J4 - SUPPORT BOARD - W4L07563 1"x2 3/8"x26 1/8" (24x60x662)


STEP 18

IF PLACING ON CONCRETE, MOVE WALL/POST ASSEMBLY ASIDE AND INSTALL CONCRETE ANCHORS USING THE SAME PROCEDURE USED PREVIOUSLY (STEP 12).

IF NOT PLACING ON CONCRETE, LEAVE WALL/POST ASSEMBLY IN PLACE.













(4) - 90° L-BRACKET - BLK - A4M00555





(2) J1 - TABLE TOP RAIL - W4L07561 2"x3"x84 1/2" (50x76x2146)















(1) TT2 - TABLE TOP ASSEMBLY - W2A02105 1 5/8"x17 5/8"x27 7/8" (40x448x708)







(4) J2 - TABLE TOP RAIL - W4L07562 1"x3"x12 1/4" (24x76x310)









(1) WP2 - PERGOLA POST - W2A02097 5 1/2"x5 1/2"x37 1/8" (140x140x943)

(1) M1 - WALL RAIL - W4L07559 5/8"x3 3/8"x95 1/2" (16x86x2426)

STEP 24 PLACE RAIL/POST ASSEMBLY IN POSITION AS SHOWN. USE CHALK AND TRACE AROUND FOOT (NOT NECESSARY IF NOT PLACING ON CONCRETE).








STEP 25


IF PLACING ON CONCRETE, MOVE RAIL/POST ASSEMBLY ASIDE AND INSTALL CONCRETE ANCHORS USING THE SAME PROCEDURE USED PREVIOUSLY (STEP 12).


IF NOT PLACING ON CONCRETE, LEAVE RAIL/POST ASSEMBLY IN PLACE.























.

(2) G2 - SEAT - W4L07553 1"x5 1/4"x39 1/2" (24x134x1002)


STEP 29





(2) G1 - SEAT - W4L07719 1"x5 1/4"x92 7/8" (24x134x2360)










(4)

(2) H4 - BRACE - W4L07554 1"x3 3/8"x12 1/4" (24x86x312)











(2)

H4 - BRACE - W4L07554 1) 1"x3 3/8"x12 1/4" (24x86x312)








(1) N1 - CLEAT - W4L07555 5/8"x2 3/8"x10 3/8" (16x60x262) (1) N2 - CLEAT - W4L07556 5/8"x2 3/8"x8 7/8" (16x60x226)








(1) FP1 - POST CAP - W2A02101 1 7/8"x6 1/2"x6 1/2" (48x164x164)

STEP 34

(4) SCREW PFH
8x2 BLK



Limited Warranty

This Limited Warranty by Backyard Discovery applies to products manufactured under the Backyard Discovery brand or its other brands including but not limited to Backyard Botanical, Adventure Playsets, and Leisure Time Products.

Backyard Discovery warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. This one (1) year warranty covers all parts including wood, hardware, and accessories. All wood carries a five (5) year pro-rated warranty against rot and decay. Refer to the schedule below for charges associated with replacement of parts under this Limited Warranty. In addition, Backyard Discovery will replace any parts within the first 30 days from date of purchase found to be missing from or damaged in the original packaging.

This warranty applies to the original owner and registrant and is **non-transferable**. Regular maintenance is required to assure maximum life and performance of this product and failure by the owner to maintain the product according to the maintenance requirements may void this warranty. Maintenance guidelines are provided in the Owner's Manual.

This Limited Warranty does not cover:

- Labor for any inspection
- Labor for replacement of any defective item(s)
- Incidental or consequential damages
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use, failure due to loading or use beyond the capacities stated in the applicable Assembly Manual.
- Acts of nature including but not limited to wind, storms, hail, floods, excessive water exposure
- Improper installation including but not limited to installation on uneven, unlevel, or soft ground
- Minor twisting, warping, checking, or any other natural occurring properties of wood that do not affect performance or integrity

Backyard Discovery products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the unit leading to failure and possible injury. Modification voids any and all warranties and Backyard Discovery assumes no liability for any modified products or consequences resulting from failure of a modified product.

This product is warranted for RESIDENTIAL USE ONLY. Under no circumstance should a Backyard Discovery product be used in public settings. Such use may lead to product failure and potential injury. Any and all public use will void this warranty. Backyard Discovery disclaims all other representations and warranties of any kind, express or implied.

This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states do not allow the limitation or exclusion of consequential damages and therefore this limitation may not apply to you.

| Pro Rated Part Replacement Schedule | | - - - - |
|--|------------------------------------|------------------|
| Product Age All Parts | <u>Customer Pays</u> | |
| 0-30 days from date of purchase 31 days to 1 year | \$0 and free shipping \$0 + S&H | |
| Wood Rot and Decay Only | | |
| 1 year | \$0 and free shipping | |
| 2 years | 20% + S&H | |
| 3 years | 40% + S&H | |
| 4 years | 60% + S&H | |
| 5 years | 80% + S&H | |
| Over 5 years | 100% + S&H | - |