



Live life Comfortably.®

CARE AND MAINTENANCE

Be careful to never allow water to build up in frames as this will cause corrosion and freeze damage in cold climates. Wash all frames with a solution of mild soap and water. Rinse with clean water and dry with a soft absorbent cloth towel. Frames can be treated with a liquid wax for maximum protection against UV rays and/or salty, damp air. If your set includes cushions, slings, and/or an umbrella, they may be cleaned by hand with a solution of soap and water with a clean water rinse. Never machine wash cushions, slings or umbrella covers as this will result in shrinkage or damage. After cleaning cushions, tip on end and allow to drip dry. Never use a commercial or home dryer to tumble dry fabric goods. Do not use bleach or solvents to clean any product! This will void the warranty. **NOTE: Lack of original receipt will void the warranty!**

CUSTOMER SERVICE

Monday - Friday 8:00 a.m. - 5:00 p.m. EST

customerservice@lazboyoutdoor.com

(877) 592-7514

www.lazboyoutdoor.com

© 2019 La-Z-Boy Incorporated

La-Z-Boy® is a trademark of La-Z-Boy Incorporated and is used under license to BJI, Inc./Casual Living Brands