


Caution

This product is fragile, do not exert too much strength or drop it during the assembly and use. Be sure to place it on the table securely.

1) Schematic diagram




2) List of Components

No.	Name	Quantity
1	Adapter	1 pc
2,3	Power Wire (longer +shorter)	2 pc
4	Holder - Lower	1 pc
5	Holder- Middle	1 pc
6	Holder- Upper	1 pc
7	Lamp	1set
8	Topper	1 pc
9	Screws (bigger +smaller)	4+8 pcs
1,2,3,4	All wire connectors.	


3) Assembling steps

I. Assemble the holder




Assemble the 3 parts of the holder into a hole with 8 screws. **Note:** Be sure to have the corresponding anchor points lined up correctly before fixing.

II. Fix holder & connect wires



- (1) Thread the shorter power wire and its connector (4) through the holder and then fix the holder onto the bottom of lamp with 4 bigger screws. **Note:** Be sure to keep the anchor points corresponded before fixing.
- (2) Fix two connectors (3) and (4) to combine two power wires of 2 and 3.

III. Power on and enjoy



- (1) Fix two connectors (1) and (2), and then connect the adaptor with the main power source.
- (2) Set the switch on the bottom of the lamp to the left. The lights should be lit, snowflakes should be falling and music should be playing. If it fails to perform such functions, check if the connectors are well connected until it can perform the functions. You can also turn the switch to the right side to turn off the music.