CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	Chair Back		2X
2	Chair/Sofa side-1	Ĩ	3X
3	Chair/Sofa Side-2		3X
4	Chair Bottom		1X
5	Sofa Back		1X
6	Sofa Bottom		1X
7	Table Side		2X
8	Table Apron		2X
9	Table Top	$\langle \rangle$	1X
10	Chair Cushion		2X
11	Sofa Cushion	$\langle \rangle$	1X
А	Allen bolt(M6x19 mm)		12X
В	Allen bolt(M6x38 mm)		8X
С	Flat washer	0	20X
D	Allen key		1X

SAFAVIEH

Model# FOX6005A / FOX6005B / FOX6005C SAMOS OUTDOOR LIVING SET Product Dimensions:

23.6"x24.4"x33.5" H (Chair) 42.9"x24.4"x33.5" H (Sofa) 36.2"x18.1"x18.5" H (Table)





Serial Number

Purchase Date	
---------------	--

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 45 minutes.

Tools Required for Assembly (included): Allen Key

