



Item	Stock#	Description	QTY
1	PS76101A-001	left front cover	1
2	PS76101A-002	left housing	1
3	PS76101A-003	motor	1
4	PS76101A-004	motor retaining plate	1
5	PS76101A-005	shock pad	4
6	PS76101A-006	screw ST4x10	2
7	PS76101A-007	fan	1
8	PS76101A-009	button spring	1
9	PS76101A-010	switch button	1
10	PS76101A-011	un-locked button spring	1
11	PS76101A-012	un-locked button	1
12	PS76101A-013	lead wire	1
13	PS76101A-014	switch	1
14	PS76101A-015	18V battery 1.5Ah	1
15	PS76101A-016	battery connector	1
16	PS76101A-017	lead wire	1
17	PS76101A-018	lead wire	1
18	PS76101A-019	wind scooper	1
19	PS76101A-020	right housing	1
20	PS76101A-021	screw ST3x12	1
21	PS76101A-022	screw ST4x14	10
22	PS76101A-023	right front cover	1
23	PS76101A-024	connector tube	1
24	PS76101A-025	tube1	1
25	PS76101A-026	tube2	1
26	PS76101A-027	charger	1

TWO (2) YEARS LIMITED WARRANTY