



# GEVI PORTABLE BLENDER

User Manual



MODEL: GEBLA089-N

## **BEFORE USING**

Prior to using this appliance, please read the user manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of appliances. Only use the appliance in the manner described in this user's manual. Keep this user manual in a safe place where it can be easily retrieved for future reference. We recommend saving the original cardboard box, packaging material, purchase record from Amazon and responsibility statement of the vendor and warranty card for at least the duration of the legal liability for unsatisfactory performance or quality. In the event of transportation, we recommend that you pack the appliance in the original box from the manufacturer.

Once you receive this product with any damage or you are not satisfied with this product, please keep the original package in a good condition and make sure the product without any damages, and then contact our after service Email to get a replacement or refund directly.

**Please kindly contact with us in advance before you make any decision  
on your amazon buyer account.**



## TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	1
DESCRIPTION OF THE PORTABLE BLENDER	5
BEFORE FIRST USE	9
USING THE PORTABLE BLENDER	9
CLEANING AND MAINTENANCE	14
RECIPES	15
TECHNICAL SPECIFICATIONS	25
DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT	25
GUARANTEE POLICY	26

# IMPORTANT SAFETY INSTRUCTIONS

When using the electrical appliance, the below basic safety precautions should be followed:

1. Please read the instructions carefully before using this product.
2. When the product is working, it is strictly forbidden to open the blender and touch movable parts such as blades and motors, so as to avoid injury or damage to the product.
3. Do not open the blender, until the blade has stopped rotating.
4. Do not disassemble or alter the product by yourself.
5. Never run the appliance under empty condition (i.e. no food in juice cups).
6. Do not place in or near flammable gases, electric stoves, or in hot ovens.
7. Do not immerse the power adapter and motor combination in water or other liquid to avoid the risk of fire, electric leakage or personal injury.

8. Do not place the product in high temperature, strong magnetic field, flammable and explosive gas (such as natural gas, methane, etc.) environment to avoid causing accidents such as abnormal operation or fire.
9. Do not put any parts of this product in a dishwasher, microwave oven, disinfection cabinet or hot water over 60 °C, or use other equipment to heat the product, in order to avoid parts deformation or damage.
10. After using the product, please clean it in time, wash the parts which are contact with food with clean water. Please be careful of the sharp blades when cleaning, so as to avoid cutting (you can wear protective gloves).
11. After charging, pull the plug out by grabbing the plug. Do not pull the wire.
12. Appliances can not be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance in a safe way by a person responsible for their safety.
13. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.

14. In the absence of supervision, the cleaning and maintenance work should not be done by the children.
15. Close supervision is necessary when the appliance is used by or near children.
16. Avoid touching moving parts.
17. Warn of potential injury from misuse.
18. Stirring ingredients such as bananas that are prone to foam may cause the product to blockage.
19. Use of accessories not recommended or sold by the original manufacturer may cause risks of fire, electric leakage or personal injury.
20. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
21. This equipment must be used in accordance with the instructions, and must not be used for other purposes.
22. Before using, please make sure that the mainframe is firmly fixed.
23. Never attempt to shield the safety interlock of the main engine.

24. Please keep this manual for future reference.

## **NOTES ON THE CORD PLUG**

The product has built-in lithium batteries. Pay attention to the following items:

1. Store and use this product in an environment of 0-40°C.
2. If not used for a long time, please charge every three months to prevent battery damage.
3. Charging speed may be slower in the environment below 10°C , which is a normal phenomenon.
4. Please charge the battery in time when the power is insufficient.

## **DESCRIPTION OF THE PORTABLE BLENDER**

### **Portable Design**

Super lightweight design with a portable size of 300ml, this cordless portable blender is as compact as a normal water bottle. You can put it in your bag, backpack or take it in your hand at any time, which is very perfect for office, home, travel and sport with on-the-go portability. Easily double-click, shake and blend, a delicious fresh juice is ready.

### **Magnetic Suction Charging**

The magnetic suction charging cable is suitable for a variety of charging methods with USB interface, so you are able to recharge this portable blender at anytime with mobile power, car adaptor, Power bank, AC adaptor etc. With this unique magnetic contact charging, no more worry about any charging problem. When using the plug to charge the blender, there are no special requirements on the plug voltage and other parameters.

### **Food-Grade Materials and BPA-Free**

With FDA approved baby food grade, 100% free of BPA. This portable blender consist of non-toxic, eco-friendly Tritan Material and SUS 301 stainless steel Blade, which is perfect for making a delicious fresh juice, fruit smoothie, milkshake and so on.




### **Double Safety Protection with Separation Automatic Shut-off**

This portable blender has a separation auto shut-off function(cup lid magnetic induction). If the main unit is placed separately or the juice cup is not rotated and installed, the product does not work. And Double-click the button switch for start can avoid touching the switch accidentally.

### **Easy to Clean and Safe to Use**

This portable blender design with IP68 Waterproof which makes it easier to clean, you are able to wash the juice cup and the blade on the main machine with water directly. For the purpose of safety, the concave design of the stainless steel blade inside the blender helps you avoid being cut while cleaning.

## PRODUCT INTRODUCTION



### CHARGING MODE:

A)When the adapter is connected, the LED indicator light is red.

B)When full of electricity, the LED indicator light is white.

For the first time, please make sure to charge the blender for more than two hours to extend the battery life. (Even the white light shows it's full.)

## **WORKING MODE:**

There is only one switch unit. The specific functions are as follows:

A) Double-click the button switch, the white light of the LED indicator lights up, then the product runs at full speed. When the working voltage is lower than 7.2V, the indicator turns to red light and flashes three times, then the machine stops running. If the indicator light flashes during the work, it means that the battery is fast exhausted.

B) If the stall occurs during operation, the product will stop immediately and the white light of the indicator will start to flash. During the process of flashing the indicator light, in order to protect the control board, the product will not respond even pressing the button switch.

C) During the working process, press the button switch, and then the portable cup stops running.

D) The red light is always on during the charging process, and the white light will display after the charging process. The portable cup with full power can squeeze up to 10 cups of juice, and the main engine can be operated continuously for 5 times (each program is set to 40 seconds), each interval is not less than 3 minutes, and rest is required after 5 times.

## **BEFORE FIRST USE**


This is a potable blender designed for on the go, different from the countertop blender. For the first use it is suggested operating according to the below steps:

- 1.Unpack the appliance and place all parts on a horizontal surface.
- 2.Before using this product for the first time, it is recommended that you should clean the juice cup and the blade on the main machine with water and dry these parts thoroughly. The main unit should be wiped with a damp cloth instead of soaked with water.

## **USING THE PORTABLE BLENDER**

- 1.Before using the product for the first time, please ensure that the battery is fully charged and thoroughly clean the blender. This product has double safety protection, if the main unit is placed separately or the juice cup is not rotated and installed, the product does not work and the LED indicator light is white and flashing when you press the button switch. Only when the main unit and the juice cup are rotated and fixed in place, you can double-click the “button switch” to start the work, and the working status indicator is white. The details will be described in the following.

2.The fruits (apples, pears, etc.) shall be washed, peeled and nucleated, and cut into squares of about 1 cm \* 1 cm \* 1 cm.




**Note:**

- 1.Please remove all hard seeds before juicing.**
- 2.It is not recommended to process coconuts or similar hard foodstuffs, since this may damage the main engine.**
- 3.It is not recommended to process hard fruit or vegetable rich in fiber and starch, such as sugarcane.**
- 4.The peel and pits should be removed from oranges, lemons, grapefruits and melons.**
- 5.If you want to blend ice, please make sure the ice cubes are 1\*1\*1cm in volume and add liquid before blend.The ice you add should not exceed six grains.**

3. Put the prepared fruits into the juice cup, add water, milk or other liquids according to your preference. The total amount of food and liquid should not exceed the maximum mark (300mL) of the cup. The maximum mark is covered by the rubber pad.



4. Rotate and install the main engine on the juice cup. The main engine and the juice cup should be tightened and installed in place to ensure that the juice will not leak out.




5. Turn the product upside down, then double-click the "button switch" on the product mainframe in a quick way, put it on the desktop or hold it in hand, then the product starts to work. The product sets a single cycle time of 40 seconds. In the process of work, shake the blender upside down to keep the material from stucked on the blade, so that the mixing effect is better and the taste of juice is more delicate.

**Note:**


**1. During the working process, click the "button switch" once, the blender will stop working immediately.**

**2. If the blade is stuck at the start of work, you can place the blender upright, and place it upside down after it works normal.**


**3. When in use, tighten the main engine and juice cup to align the two points, otherwise the juice cup will not start properly.**



6. After mixing and making the juice, rotated out the main machine from the juice cup, and the juice in the juice cup can be directly drunk.



7. Insert the magnetic suction charging cable into the DC5V/1A standard USB plug, and attach the magnetic suction head of the charging wire to the magnetic suction joint of the main engine to charge the product. The LED indicator is red when you charging the blender, and after charging, the indicator will turn to white. The product will not work during the all charging process. If the red light does not work during charging, please check whether the charging cable is placed properly and ensure to use the cable made by the regular manufacturer.





## CLEANING AND MAINTENANCE

1. Make sure the blade has stopped running before cleaning.
  2. Do not use steel ball, abrasive cleaner or corrosive liquid (such as gasoline, acetone) to clean this product.
  3. The main unit can be wiped with a wrung wet cloth. Do not rinse, soak or spray the main unit in water or other liquids to avoid causing damage to the device or product leakage.
  4. Use clean water to rinse the inside of the juice cup and the parts which are contacting with food, and wipe dry or airing them in time. Please operate carefully to avoid cutting (protective gloves can be worn) during the cleaning process.
  5. When storing the portable blender, please ensure that the product has already cleaned and dried, then place it in a dry, ventilated place to avoid direct sunlight.
  6. Fast Cleaning Process: Add appropriate amount of water into the juice cup and install it on the main engine. Double-click the "Button switch" to start the product and work for 5 to 10 seconds.
- Caution: The blender can not be pasteurized in the disinfection cabinet.**

## RECIPES

### Strawberry Lemon Juice

Strawberry ..... 90 g

Lemon juice ..... 3 ml

Pure water ..... 200 ml

1. Wash and stem the strawberries.
2. Put all the materials into the blender and then start the machine and mix well.



## Banana Mango Smoothie

Banana .....	30 g
Mango .....	30 g
Yogurt .....	90 ml
Ice .....	18 g
Honey .....	6 g

1. Peel bananas and cut into small pieces, peel and core mangoes. Then, refrigerate bananas and mangoes until firm.
2. Put all the materials into the blender and then start the machine and mix well.



## Blueberry Banana Milk

Blueberries ..... 5 pieces  
Banana ..... 1/4 root  
Milk ..... 100 ml

1. Wash the blueberries. Peel the bananas and cut into small pieces.
2. Put all the materials into the blender and then start the machine and mix well.



## Banana Avocado Juice

Banana ..... 1/4 root  
Avocado..... 1/4 unit  
Milk ..... 100 ml

1. Peel the banana and cut it into pieces. Cut the avocado in half, unscrew the core and peel the diced.
2. Put all the materials into the blender and then start the machine and mix well.



## Cantaloupe Soybean Juice

Soybean .....	40 g
Honeydew melon .....	170 g
Lemon juice .....	3 ml
Purified water .....	100 ml

1. Peel the Honeydew melon and cut into small pieces. Clean and cook the Soybean, then cool the Soybean after cooking.
2. Put all the materials into the blender and then start the machine and mix well.



## Healthy Yogurt Milkshake

Strawberry .....	3 unit
Banana .....	1 unit
Blueberry .....	10 pieces
Yogurt .....	100 ml
Oatmeal .....	30 g
Orange .....	1/2 unit

1. Wash and stem the strawberries, then cut them in half. Peel and cut the bananas into small pieces. Clean the blueberries. Peel and cut the oranges into pieces.

2. Pour oatmeal and yogurt into the blender first, then add other fruits, let stand for 10 minutes, then start the machine and mix well.



## Mashed Carrot Apple

Carrot .....	30 g
Apple .....	60 g
Purified water.....	400 g

1. Peel the carrots and cut them into small pieces. Peel and core the apples and cut into small pieces. Add water to pan carrots and apples until soft and cool them after boiling.
2. Pour carrots and apple cubes into the blender cup. Pour the water from the fruits and vegetables to the highest line, start the machine to stir them into mud, and remove the floating foam.





## TROUBLE SHOTTING

Please check the following content first before requesting repair:

Symptom	Confirmation matters	Take steps
Product does not start	<ul style="list-style-type: none"><li>• Is it used continuously for a long time?</li><li>• Is the food stuck on the blade?</li><li>• Is the host and the juice cup not rotated in place?</li><li>• The red light flickered.</li></ul>	<ul style="list-style-type: none"><li>• Please wait for the motor to cool down before using.</li><li>• Please remove the remaining food and use it again.</li><li>• Please install the host and juice cup in place before starting.</li><li>• Please fully charge before use.</li></ul>
When working, the blade is stuck and the lamp flashes	<ul style="list-style-type: none"><li>• The fruit granules are too large to cause the stuck of the blade.</li><li>• Fruits and liquids exceed the maximum scale rated by the product.</li></ul>	<ul style="list-style-type: none"><li>• The fruits (apples, pears, etc.) were washed, peeled and nucleated, and cut into small squares of about 1 cm*1 cm*1cm.</li><li>• Don't let the blade touch the pulp first, then turn on and put it in position.</li><li>• Reduce the liquid capacity not to exceed the rated capacity of the cup.</li></ul>

<p>Motor burnt smell</p>	<ul style="list-style-type: none"> <li>• Whether continuous use time is longer.</li> </ul>	<ul style="list-style-type: none"> <li>• The high-powered motor is inside the main unit Due to the friction of the carbon brush, an odor will occur, but it is not a product failure.</li> <li>• Please feel free to use.</li> </ul>
<p>Charging without prompt (red light not on)</p>	<ul style="list-style-type: none"> <li>• Bad connection of magnetic suction charging cable.</li> <li>• Due to the identification restrictions of some branded adapters on the electrical equipment, the actual output voltage and current do not meet the requirements.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the connection status of magnetic suction charging cable to ensure that the connection is normal.</li> <li>• Please charge the product with the universal adapter of DC5V/1A and above, which is purchased through regular channels.</li> </ul>

## PRECAUTIONS



**Be alert to the risks that may lead to danger, serious injury and heavy property loss.**

1. Do not soak the main engine into the water.
2. Do not put overheated ingredients or liquid ( 60 °C) into the juice cup to avoid bursting and splashing the juice cup.
3. This product contains lithium-ion batteries. It is strictly forbidden to disassemble the shell of the product without permission to avoid the damage to core or other hazards.
4. It is strictly forbidden to disassemble, squeeze, puncture, or short circuit the product, or put it into water or fire, or an environment where the temperature is higher than 60 °C.

**CAUTION: Pay attention to the risk of personal injury or damage to goods.**

5. The product has built-in lithium batteries. Pay attention to the following items:
  - A) Store and use this product in an environment of 0-40 °C.
  - B) If not used the product for a long time, please charge every three months to prevent battery damage.
  - C) Charging speed may be slower than usual in the environment below 10 °C, which is a normal phenomenon.
  - D) Please charge the battery in time when the power is insufficient.

## TECHNICAL SPECIFICATIONS

Model Number: GEBLA089-N

Rated Voltage: DC7.4V

Rated Power Input: 50W

## DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT



Please remember to respect the local regulations: This symbol on products or original documents means that used electric or electronic products must not be added to ordinary municipal waste.

For proper disposal, renewal and recycling hand in the non-working electrical equipment to an appropriate waste disposal center. What is more, a correct disposal of this product helps save valuable natural resources and prevents potential negative effects on the environment and human health, which could result from improper waste disposal.

## **GUARANTEE POLICY**

Consumers get ONE-YEAR warranty of this product. The warranty period is from the purchasing date of your order ID on Amazon.

Once you have any problem of this product, please feel free to contact with our consumer service Email to get support from our Service Team.

Thank you again for purchasing GEVI products from Amazon.

Please kindly read all the other documents in our package to get further information and your thank-you gift.