


HAIKU REMOTE :

FANS

Before using the remote control, remove the plastic tab from the battery tray. The remote must be pointing toward the fan to function properly.



⚠ Do not expose the remote control to rain or water.