

PS-12 (Part #1112710)

Description	PART #	
*KETTLE (SQUARE)	101201	
DECAL SET	512110	
DOOR LEFT (21" X 10 5/8")	512502	
DOOR RIGHT (21" X 10 5/8")	512503	
DRAWER-OLD MAID	511145	
DROP DOOR	595136	
DROP DOOR/TRAY	595135	
*ELEMENT/KETTLE	516126	
ELEMENT/WARMER (2)	516041	
GAS SPRING	516066	
FEET FOR BASE (4)	540322	
*GEAR MOTOR	512096	
GLASS-FRONT	512504	
Size(22.33" X 30.12" X .125")		
Size(567mm X 765mm X 3.2mm)		
EXTRUSION-FRONT-UPRIGHT (need 2 per glass)	18177	
EXTRUSION-FRONT-BASE (need 1 per glass)	18174	
FRONT/SIDE POPCORN DECAL	91217	
GLASS-SIDE	512507	
Size(17.33" X 30.12" X .125")		
Size(440mm X 765mm X 3.2mm)		
EXTRUSION-SIDE-UPRIGHT (need 2 per glass)	18177	
EXTRUSION-SIDE-BASE (need 1 per glass)	18173	
HINGE SET	512403	
KETTLE HANDLE	516053	
KETTLE LID COMPLETE	516055	
KETTLE LID SPRING	516065	
KETTLE LID LEVER	516063	
KETTLE PLUG (Old-Round)	518003	
KETTLE PLUG (New-Square)	518320	
BULB (50 Watt Flood Light)	512161	
MAGNET SNAP ON	512100	
PIGTAIL (Old-Round)	540327	
PIGTAIL (New-Square)	512510	
PILOT LAMP SET	540321	
PIN&CLIP KETTLE LG	516092	
*POWER CORD	590013	

SOCKET KETTLE NEW	512194	
SOCKET KETTLE OLD	518002	
LAMP SOCKET	512155	
STIRRER	512505	
*SWITCH SET (4)	512506	
TERMINAL BLOCK	512049	
THERMOSTAT	512139	
TOP W DECALS	595363	
BLACK ENDCAPS (Set of 4)	512107	
OPERATING INSTRUCTION DOOR DECAL	90010	

*For use in Domestic (120v) models only

Export Parts (Part # 1212710)

KETTLE (Square Plug)	131201	
POWER CORD	590014	
GEAR MOTOR	512095	
KETTLE ELEMENT	516123	
SWITCH SET (4)	512508	
WARMER ELEMENT (2)	516041	