


USE AND CARE GUIDE

OUTDOOR WALL LANTERN



Questions, problems, missing parts? Before returning to the store, call Monteaux™ Lighting Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

1-800-446-9092

THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	2
Pre-Installation	
Planning Installation	3
Tools Required	

Hardware Included	
Package Contents	4
Installation	5
Operation	6
Care and Cleaning	6
Troubleshooting	

Safety Information

☐ Consult a qualified electrician if you have any electrical questions.



CAUTION: Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation. Please call our Customer Service Team at 1-800-446-9092.



WARNING: Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

Warranty

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of one (1) year from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect, or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.


Contact the Customer Service Team at 1-800-446-9092.

Pre-Installation


PLANNING INSTALLATION

- ☐ Read all instructions before installation.
- ☐ To avoid damaging this product, assemble it on a soft, non-abrasive surface, such as carpet or cardboard.
- \square Keep your receipt and these instructions for proof of purchase.

TOOLS REQUIRED




HARDWARE INCLUDED




Part	Description	Quantity
AA	Mounting unit	1
BB	Mounting screw	2
CC	Wire nut	3
DD	Cap nut	2

Pre-Installation (continued)

PACKAGE CONTENTS





Part	Description	Quantity
Α	Light fixture	1
В	Edison bulb	1


Installation

Attaching the mounting unit to the junction box

☐ Attach the mounting unit (AA) to the junction box (not included) with mounting screws (BB).



NOTE: The pre-installed support screws on the mounting unit (AA) should protrude out away from the junction box.





2 Making the electrical connections

- Connect the copper wire from the light fixture (A) to the mounting unit (AA) by securing it with the pre-installed ground screw.
- Connect the black to black (power), the white to white (neutral), and copper wire to ground wire with the wire nuts (CC) and secure the wire nuts (CC) with electrical tape (not included).




NOTE: If the wires from the fixture are the same color, attach the side with markings or letters to the black (positive) wire and the other to the white (neutral) wire.






3 Securing the light fixture to the junction box

- □ Pull up the latch and open the door on the right side of the light fixture (A) to access the interior.
- □ Secure the light fixture (A) to the junction box by placing it over the pre-installed screws on the mounting unit (AA) and securing it with the cap nuts (DD).








NOTE: The fixture is designed to be mounted facing up for the bottom drainage holes to be implemented.

4 Installing the light bulbs

Install one 60W Edison light bulb (included).



Operation

Turning the light on

 $\ \square$ Turn the light switch on to activate the fixture.

Care and Cleaning

- \Box Clean the lamp with a soft, dry cloth.
- $\ \square$ Do not use any cleaners with chemicals, solvents, or harsh abrasives.

Troubleshooting

Problem	Possible Cause	Solution
The bulb will not light.	The bulb is burned out.	Replace the light bulb.
	The power is off.	Ensure the power supply is On.
	There is a faulty wire connection.	Check the wiring.
	The circuit breaker is off.	Ensure the circuit breaker is in the On position.
The fuse blows or circuit breaker trips when the light is turned on.	There are crossed wires or the power wire is grounding out.	Check the wire connections. Contact a qualified electrician or call the Customer Service Team at 1-800-446-9092.



Questions, problems, missing parts? Before returning to the store, call Monteaux Lighting™ Customer Service 8 a.m. - 6 p.m., EST, Monday-Friday

1-800-446-9092

Retain this manual for future use.