




Item #530-162  
Model #13-0010-ADA

# USE AND CARE GUIDE

---

## WALL-MOUNT BATHROOM SINK



Questions, problems, missing parts? Before returning to the store,  
call Glacier Bay Customer Service  
8 a.m. - 6 p.m., EST, Monday-Friday

**1-855-434-5224**

**HOMEDEPOT.COM**

---

### **THANK YOU**

*We appreciate the trust and confidence you have placed in Glacier Bay through the purchase of this sink. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Glacier Bay!*

# Table of Contents

Table of Contents.....	2	Pre-Installation.....	3
Safety Information.....	2	Installation .....	5
Warranty.....	2	Care and Cleaning .....	6

# Safety Information



**WARNING:** Handle with care. Vitreous chinaware is glass-like with sharp edges if broken. Do not drop, handle roughly, or overtighten bolts.

**NOTICE:** Observe local plumbing and building codes.

# Warranty

Glacier Bay products are manufactured with superior quality standards and workmanship and are backed by our limited lifetime warranty. Glacier Bay products are warranted to the original consumer purchaser to be free of defects in materials or workmanship. We will replace **FREE OF CHARGE** any product or parts that proves defective. Simply, return the product / part to any of The Home Depot retail locations or call 1-855-HD Glacier (1-855-434-5224) to receive the replacement item. Proof of purchase (original sales receipt) from the original consumer purchaser must be made available for all Glacier Bay warranty claims.

This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse or normal wear and tear. This warranty excludes all industrial, commercial & business usage, whose purchasers are hereby, extended a five year limited warranty from the date of purchase, with all other terms of this warranty applying except the duration of warranty.


Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state and province to province. Please see a store or contact 1-855-HD Glacier for more details.

# Pre-Installation

Locate the proper position for the wall-mount sink in your bathroom. Be sure to have access to plumbing and drain fittings.




**NOTE:** This wall-mount sink is for the handicapped. You have to install to meet ADA height requirements. The recommended height from the rim to the floor is 33-34 inches.



## TOOLS REQUIRED



Carpenter Level



Caulk



Pencil




Screwdriver




Wrench



Stud Finder



Drill




Tape Measure

## HARDWARE INCLUDED



**NOTE:** Hardware not shown to actual size.



AA



BB



CC




DD

Part	Name	Quantity
AA	Lag screw	2
BB	Toggle bolt	2
CC	Steel washer	2
DD	Rubber washer	2

# Pre-Installation (continued)

## PACKAGE CONTENTS



Part	Name	Quantity
A	Wall-mount sink	1
B	Mounting bracket	1


# Installation

## 1 Preparing the installation location



**CAUTION:** The sink is heavy. It may be necessary to install a 2 in. x 4 in. board behind the finished wall.

- Position the board between two studs so that the front surface of the bracket is flush with the front of the studs. The finished wall is then applied over the boards.
- Each wall-mount sink has two holes at the backplate for the placement of additional anchor screws. The solid structure of the wall must be present in order to place anchor screws through these holes.




## 2 Marking the mounting bracket location

- Hold the mounting bracket (B) against the wall at the suggested height (29.75 in. to 30.75 in.). Measure from the center of the slot to the floor.
- Use a pencil to mark the locations on the wall.



**NOTE:** Ensure the bracket is centered over the waste outlet hole (1) and the plumb line of the screws is centered in the slots.




## 3 Installing the bracket

- Use a stud finder to see if there are wall studs before drilling holes into the wall.
- Put the bracket (B) in place and secure it with lag screws (AA).
- Use the screwdriver to tighten the lag screws until the pedestal basin (A) is snug against the wall.




**NOTE:** Check to see if the bracket is level before tightening into position.



## Installation (continued)

### 4 Attaching the sink

- Place the wall-mount sink (A) on the bracket (B). Ensure the rear lip of the sink (A) is securely engaged with the bracket (B), and that the sink (A) is in the middle of the bracket (B).
- Adjust the level by loosening the lag screws (AA) and raising or lowering them.
- When the sink (A) is level, tighten both screws (AA).




### 5 Securing the sink



**CAUTION:** Do not over tighten the toggle bolts (BB) as this could break the porcelain..

- Use a pencil to mark the backplate anchor screw hole's locations on the wall. Drill the holes using the 5/8 in. drill bit.
- Anchor the lower back of the sink (A) to the wall with toggle bolts (BB), steel washers (CC), and rubber washers (DD) through the right and left anchor screw holes.
- With the screwdriver, tighten the toggle bolts (BB) until the sink is snug against the wall.
- Connect and tighten the water supply fittings, waste piping, and faucet as required.



## Care and Cleaning

Clean the outside surface with mild soap, warm water, and a soft cloth. On stubborn stains use a powdered detergent and damp sponge or nylon scouring pad. Never use abrasive scouring powders, cleansers or pads because they will scratch, damage and dull the surface.



Questions, problems, missing parts? Before returning to the store,  
call Glacier Bay Customer Service  
8 a.m. - 6 p.m., EST, Monday-Friday

**1-855-434-5224**

**HOMEDEPOT.COM**

Retain this manual for future use.