

GETTING TO KNOW YOUR DEHYDRATOR

PREPARING YOUR DEHYDRATOR FOR USE

LIST OF COMPONENTS

1. **On/Off switch**
2. **Variable Temperature Control Dial**
3. **Door**
4. **Dehydrating Trays (NOT DISHWASHER SAFE)**
5. **Door Latch**
6. **Non-stick drip sheet (Not Pictured)**



FIRST TIME USE / CLEANING INSTRUCTIONS

1. Remove the appliance from its packaging. Make sure all parts are present and undamaged. Save packaging if needed or dispose of waste properly.
2. Thoroughly **HAND** wash the trays with warm soapy water and dry completely. **TRAYS ARE NOT DISHWASHER SAFE.** Do not submerge base of appliance in water. Do not let water get into the fan area.
3. Place appliance on flat, stable surface such as a table or bench. One by one, add trays to the dehydrator making sure that they are all securely in place.
4. Turn ON/OFF switch to the ON position. Set temperature dial to 90 degrees, and allow unit to run for 45 minutes. This will remove any moisture inside still present from the initial cleaning.

USING YOUR DEHYDRATOR

OPERATING INSTRUCTIONS

1. Make sure the power switch is turned to OFF.
2. Place the appliance on a dry, clean surface away from children, pets and flammable liquids.
3. Plug the appliance into a standard wall outlet. Make sure the electrical outlet is not damaged. Position the appliance at least 6 inches from any wall or object to allow for proper air flow.
4. Make sure all packaging materials have been removed from appliance.
5. Turn the power switch to ON. The dehydrator will begin to heat up quickly.
6. Preheat the appliance for 15 minutes prior to loading trays into the unit.
7. Follow recipes and preparation guidelines for the food you want to dehydrate.
8. Remove any excess marinade or liquid from the food. Excess liquid will increase dehydrating time, pat dry with a clean paper towel.
9. Use hand protection when sliding trays out for loading the food. Allow ¼" to ½" between the food pieces for air circulation and even drying.
10. Slide the trays carefully back into the dehydrator, using two hands if needed.
11. Latch the dehydrator door to ensure that the appliance will work properly.

(continues on next page)