



**ZINSSER®
PAINT DEGLOSSER**

DESCRIPTION AND USES

Zinsser® Paint Deglosser is designed to clean and prepare dirty and glossy surfaces for painting or staining. Paint Deglosser eliminates the need for sanding and helps new finishes bond to the prepared surface. It also helps to minimize chipping, cracking and peeling between finishes. It works on all types of paints, enamels, varnishes and stains. It is suitable for use on wood moldings, kitchen cabinets, door facings and furniture.

PERFORMANCE CHARACTERISTICS

- Prepares glossy surfaces for new finishes
- Removes dirt, stains, grease and wax
- Helps new paint bond to old finishes

PRODUCTS

SKU	Description
42124	1-Quart

PRODUCT APPLICATION

SURFACE PREPARATION

Spread a solvent resistant drop cloth covered with newspapers around the work area in case of drips and spills. Protect eyes and skin. Wear safety goggles and chemical resistant gloves. Keep away from heat, sparks and flames.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-Approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

PRODUCT APPLICATION (cont.)

APPLICATION

USE ONLY WITH ADEQUATE VENTILATION. Apply only when air and surface temperatures are between 65-90°F (18-32°C) and the relative humidity is below 85%. Shake can before using and open can carefully to relieve pressure. Saturate a clean, lint-free cloth with Paint Deglosser. Clean the surface completely by rubbing surface in a circular motion. Fold and re-saturate the cloth frequently to prevent re-depositing of contaminants. Finish by applying a moderate coat of Deglosser. Allow the surface to dry for 30 minutes before applying a new finish. For best results, apply a new finish within one hour of applying the Paint Deglosser.

SPILLAGE

Open containers carefully and close after each use. If spilled, contain spilled material and remove with an inert absorbent. Dispose of contaminated absorbent, container and unused contents in accordance with local, state and federal regulations. Clean up rags, papers and waste promptly. Allow solvent to evaporate, then dispose of in a metal container.

CLEAN-UP

Clean up tools and brushes with soap and water.

**TECHNICAL DATA****ZINSSER® PAINT DEGLOSSER****PHYSICAL PROPERTIES**

Physical Properties		PAINT DEGLOSSER
Composition		Isopropanol, Petroleum Distillates
Weight	Per Gallon	6.7 lbs.
	Per Liter	0.80 kg
Volatile Organic Compounds		800 g/l
Practical Coverage		Varies with thickness and type of coating
Shelf Life		5 years
Flash Point		46°F (8°C)
Caution!		Causes eye, skin, nose and throat irritation. Do not get in eyes, on skin or clothing. May be harmful if absorbed through skin. Wash thoroughly after handling. KEEP OUT OF REACH OF CHILDREN.
Safety Information		For additional information, see MSDS

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.