

PL171213 Drum Auger

For Clogged Sinks, Showers and Tub Drains

Instructions:

1. Remove drain stoppers.
2. Loosen thumbscrew to release the cable.
3. Pull and insert the cable into drain until blockage is reached.
4. Tighten thumbscrew to lock the cable.
5. Turn handle to rotate the cable clockwise and hook the clog. Blockage may be pushed down or pulled out. Repeat as necessary.
6. Cable must be washed clean and air dried before storage.

Warning:

Read instructions before use. Manufacturer will not be held responsible for damages caused by improper use.

PL171214 Power Drum Auger

For Clogged Sinks, Showers and Tub Drains

Instructions:

1. Remove drain stoppers.
2. Attach power drill to auger's shaft connector.
3. Loosen thumbscrew to release the cable.
4. Pull and insert the cable into drain until blockage is reached.
5. Tighten thumbscrew to lock the cable.
6. Start drill at LOW speed to rotate the cable clockwise and hook the clog. Blockage may be pushed down or pulled out. Repeat as necessary.
7. Cable must be washed clean and air dried before storage.

* It's optional to use power drill. To use manually please refer to instructions for PL171213.

Warning:

Read instructions before use. Keep power drill out of water at all times. Manufacturer will not be held responsible for damages caused by improper use.

Drain Auger

For Clogged In-house Pipes

Instructions:

1. Remove drain stoppers.
2. Feed the cable through the provided hollow handle.
3. Feed the cable into the clogged sink until blockage is reached.
4. Adjust handle and tighten thumbscrew.
5. Crank the handle to twist the cable clockwise and hook the blockage.
6. Pull out blockage and flush drain.
7. Cable must be washed clean and air dried before storage.

Warning:

Read instructions before use. Manufacturer will not be held responsible for damages caused by improper use.

PL171207 Encased Sewer Tape

For Clogged Sewer Pipes

Instructions:

1. Use one hand to hold the handle or the black casing on top depending on the model you purchased.
2. Use other hand to rotate the casing outward so the rod will come out.
3. Feed the rod into the sewer pipeline until the end meets the blockage.
4. Blockage may be pushed down or pulled out. Repeat as necessary.
5. Clean and air dry the rod before feeding back into the casing.
6. To retract the rod, rotate the casing inward.

Warning:

Read instructions before use. Manufacturer will not be held responsible for damages caused by improper use.

PL171205 Toilet Auger

Instructions:

1. Pull handle all the way to the end.
2. Insert auger into toilet and place the curved rubber part against the bottom of toilet bowl.
Be careful not to scratch porcelain.
3. Push and rotate handle clockwise to feed the cable as far as it will go.
4. Pull handle back slowly and flush toilet.
5. Auger must be washed clean and air dried before storage.

Warning:

Read instructions before use. Manufacturer will not be held responsible for injuries or damages caused by improper use.