



**WASHER TOSS  
PREMIUM SET**

VIVA SOL. Translated: “Long live the Sun”  
And long live all the fun you can have  
under it. Viva Sol creates memorable  
outdoor experiences by combining  
craftsmanship with gamesmanship.

OWNER'S MANUAL



Check out our website to get more information and exciting news on other **VIVA SOL** Products.

**www.LONGLIVESUN.com**

Product Info - Playing Tips - News & Events - Replacement Parts

## GAME RULES:

- **POSITION TARGETS 20FT AWAY FROM EACH OTHER. MEASUREMENT IS FROM CUP TO CUP.**
- **THE GAME CAN BE PLAYED WITH EITHER 2 OR 4 PLAYERS.**
  - **Starting The Game:**  
Each individual or a member of each team throws a washer to determine whom tosses first. Whoever gets the highest points, or gets closest to a hole, chooses if they want go first or second. After the first round the person or team who scored last throws first the following round.
  - **For A Two Player Game:**  
Each player throws their washers from the same side, to the opposite board. The first player throws their four washers, and the second player then throws their four washers to complete one round. After all washers have been tossed, the scores are counted, and the players move to the opposite board for the next round.
  - **For Team Play (2-on-2):**  
Team members throw from opposite boards. The first player from team one tosses four washers, and then the first player from team two tosses their four washers to the same board. Count the scores. The players on the opposite board then pick up the washers and toss from their side.

## SCORING

- Points are scored when a player has a bag on the board or in the hole.
- Only one team can score points per round because points cancel each other out.
- A washer put on the board = 1 point
- A washer put in the hole = 3 points
- A washer that lands on top of any edge of the washer box = game over, you win!
- The game is over when one team scores 21 points exactly. If a score exceeds 21 a penalty is incurred. If you go over 21 points your score is reduced by the number of points you scored to cause you to exceed 21.

### Replacement Parts List for Mini Bean Bag Toss Set.

Part #	Description	Qty.
VS6000-P1	WOODEN CASE WITH YELLOW CUP	1
VS6000-P2	WOODEN CASE WITH GREEN CUP	1
VS6000-P3	WASHER RED	4
VS6000-P4	WASHER BLUE	4

## 90-Day Limited Warranty

This consumer warranty extends to the original consumer purchase of any ESCALADE® SPORTS Product (hereinafter referred as the "Product").

**WARRANTY DURATION:** This Product is warranted to the original consumer purchase of a period of ninety (90) days from the original purchase.

**WARRANTY COVERAGE:** ESCALADE® SPORTS warrants to the original Consumer Purchaser that any Product of its manufacture is free from defects in material and workmanship when used for the intended purpose under normal use and conditions. THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN DAMAGED BY ACCIDENT, UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE, FAILURE TO FOLLOW INSTRUCTIONS PROVIDED WITH THE PRODUCT OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL AND WORKMANSHIP.

**WARRANTY PERFORMANCE:** During the above ninety (90) day warranty period, ESCALADE® SPORTS shall repair or replace with a comparable model, and Product, or component thereof, which may prove defective under normal use and proper care, and which our examination shall disclose to our satisfaction to be thus defective, please contact our Warranty Dept.

1-866-873-3528 / Warranty Dept.

Or Write us at:

Escalade® Sports, Inc. - P.O. Box 889, Evansville, IN 47706 - Attn: Warranty Dept.

Or E-mail us at:

customerservice@escaladesports.com

Other than shipping requirements no charge will be made for such repair or replacement of in-warranty Products. ESCALADE® SPORTS strongly recommends that the Product is insured for value prior to mailing.

**WARRANTY DISCLAIMERS:** ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE NINETY (90) DAY WARRANTY PERIOD. ESCALADE® SPORTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE PRODUCT OR OTHER CONSEQUENTIAL OR INCIDENTAL COSTS, EXPENSES OR DAMAGES INCURRED BY THE CONSUMER OF ANY OTHER USE.

Some states do not allow the exclusion or limitation of implied warranties or consequential or incidental damages, so the above limitations or exclusions may not apply to you.

**LEGAL REMEDIES:** This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.