# IN41331 INSTALLATION INSTRUCTIONS

Phone: (866) 845-5451 • Fax: (866) 816-6165 E: service@acclaim-lighting.com • www.acclaim-lighting.com

1500 Cherokee Parkway, Suite 100, Acworth, GA 30102



Please read carefully and save these instructions, as you may need them at a later date.

### **CAUTION**

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

### **GENERAL**

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.


Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

## ASSEMBLY AND INSTALLATION

- 1. Insert plastic anchors (9) into wall.
- 2 Secure the back plate (6) to the outlet box (1) with mounting screw (8). Secure the back plate (6) to the plastic anchors (9) using two anchors screws (10).
- 3. Pull out the outlet wire and ground wire from the outlet box (1). Make wire connections.
- --Ribbed wire (w/o marking) or white wire from light to White wire (2) from power source.
- --Smooth wire (w/o marking) or black wire from light to Black wire (3) from power source.
- --Attach the ground wire (4) to back plate (6) with a ground screw (7).
- 4. Secure front plate (11) to back plate (6) with mounting screws (12).
- 5. Place the glass (15) on the glass holder (13).
- 6. Install bulbs (16) to socket (14)

(Don't exceed the maximum capacity recommended on the sockets).

### INSTALLATION IS NOW COMPLETED



- OUTLET BOX
- 2. WHITE WIRE
- 3. BLACK WIRE
- 4. GROUND WIRE
- 5. WIRE CONNECTOR
- 6. BACK PLATE
- 7. GROUND SCREW
- 8. MACHINE SCREW

- 9. PLASTIC ANCHOR
- 10. ANCHOR SCREW
- 11. FRONT PLATE
- 12. MOUNTNG SCREW
- 13. GLASS HOLDER
- 14. SOCKET
- 15. GLASS
- 16. BULB