




ASSEMBLY INSTRUCTIONS



RiverRidge® 4 TIER LADDER SHELF

ITEM #:02-070/06-094 WHITE

ITEM #:02-071/06-095 GRAY

ADULT ASSEMBLY REQUIRED

This product requires assembly by an adult because of small parts. Care should be taken in unpacking and assembling this item to keep small parts away from children.

WARNING **SEE FULL WARNING ON PAGE 2**

Young children can be seriously injured or killed if furniture tips over. Don't use this item for a TV stand or place heavy objects on top of item. Always use angle-braces or anchors to secure furniture to the wall.

Send requests for missing or damaged parts replacements by email to:

customer.service@ssi-rr.com or call toll free 1-(844)-223-5201 or order parts on line at

www.riverridgehome.com

THIS SHELF UNIT WILL HOLD UP TO 20 POUNDS PER SHELF OR A TOTAL OF 80 POUNDS. DO NOT LOAD EACH SHELF WITH MORE THAN 20 POUNDS. IF LOADED WITH MORE THAN 20 POUNDS PER SHELF THIS MAY CAUSE DAMAGE TO THE SHELF AND MAY CAUSE SERIOUS INJURY OR DEATH.























WARNING

SERIOUS OR FATAL INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- **Always use tip over restraints and/or wall anchors to secure furniture to the wall**
- **Place heaviest items in the lowest drawers/bins or shelves**
- **Do not set TV's or other heavy objects on the top of this product**
- **Never allow children to climb or hang on to the drawers/bins, doors or shelves of furniture**
- **Never open more than one drawer at a time or defeat or remove any drawer interlock system**


PARTS LIST

NO	PARTS	QTY	DESCRIPTION
A		36PCS	WOOD DOWEL
B		4PCS	CAM BOLT
C		4PCS	CAM LOCK
D		16PCS	MACHINE SCREW (6X20MM)
E		32PCS	WOOD SCREW (3.5X25MM)
F		1PC	WALL SCREW (4X30MM)
G		1PC	WOOD SCREW (3X12MM)
H		1PC	PLASTIC ANCHOR
J		2PCS	BRACKET
K		1PC	PLASTIC LOCK STRAP
1		1PC	TOP REAR RAIL BOARD
2		3PCS	REAR RAIL BOARD
3		1PC	SHELF #1 LEFT RAIL BOARD
4		1PC	SHELF #1 RIGHT RAIL BOARD
5		1PC	SHELF #2 LEFT RAIL BOARD
6		1PC	SHELF #2 RIGHT RAIL BOARD
7		1PC	SHELF #3 LEFT RAIL BOARD

NO	PARTS	QTY	DESCR PT ON
8		1PC	SHELF #3 RIGHT RAIL BOARD
9		1PC	SHELF #4 LEFT RAIL BOARD
10		1PC	SHELF #4 RIGHT RAIL BOARD
11		1PC	SHELF #1
12		1PC	SHELF #2
13		2PCS	SHELF #3 AND #4
14		2PCS	TOP BAR OF LEFT AND RIGHT SIDE FRAME
15		1PC	LEFT FRONT LEG
16		1PC	LEFT REAR LEG
17		1PC	RIGHT FRONT LEG
18		1PC	RIGHT REAR LEG

**TOOLS NEEDED FOR ASSEMBLY: FLAT & PHILLIPS SCREWDRIVER (NOT INCLUDED)
THE USE OF POWER SCREWDRIVER IS NOT RECOMMENDED**


STEP 1



STEP 1

1. Insert 1 wood dowel (A) into wood dowel hole on end of top rear rail board (1).
2. Attach shelf #1 left rail board (3) to top rear rail board (1) by inserting wood dowel (A) into hole on shelf #1 left rail board (3). Make sure hole on top rear rail board (1) is facing towards back side of shelf.
3. Insert 1 wood screw (E) through hole on shelf #1 left rail board (3) and tighten to top rear rail board (1).
4. Repeat above steps to assemble shelf #1 right rail board (4) to top rear rail board (1).


STEP 2



STEP 2

1. Insert 1 wood dowel (A) into wood dowel hole on end of rear rail board (2).
2. Attach shelf #2 left rail board (5) to rear rail board (2) by inserting wood dowel (A) into hole on shelf #2 left rail board (5).
3. Insert 1 wood screw (E) through hole on shelf #2 left rail board (5) and tighten to rear rail board (2).
4. Repeat above steps to assemble shelf #2 right rail board (6) to rear rail board (2).


STEP 3



STEP 3

1. Insert 1 wood dowel (A) into wood dowel hole on end of rear rail board (2).
2. Attach shelf #3 left rail board (7) to rear rail board (2) by inserting wood dowel (A) into hole on shelf #3 left rail board (7).
3. Insert 1 wood screw (E) through hole on shelf #3 left rail board (7) and tighten to rear rail board (2).
4. Repeat above steps to assemble shelf #3 right rail board (8) to rear rail board (2).


STEP 4



STEP 4

1. Insert 1 wood dowel (A) into wood dowel hole on end of rear rail board (2).
2. Attach shelf #4 left rail board (9) to rear rail board (2) by inserting wood dowel (A) into hole on shelf #4 left rail board (9).
3. Insert 1 wood screw (E) through hole on shelf #4 left rail board (9) and tighten to rear rail board (2).
4. Repeat above steps to assemble the shelf #4 right rail board (10) to the rear rail board (2).


STEP 5



STEP 5

1. Insert 6 wood dowels (A) into wood dowel holes on shelf #1 (11).
2. Attach shelf #1 (11) to shelf #1 rail board assembled parts (1), (3), (4) by inserting wood dowels (A) into wood dowel holes on left rail board (3), right rail board (4) and top rear rail board (1).
3. Insert 6 wood screws (E) through holes on shelf #1 (11) and tighten to left rail board (3), right rail board (4) and top rear rail board (1).


STEP 6



STEP 6

1. Insert 6 wood dowels (A) into wood dowel holes on shelf #2 (12).
2. Attach shelf #2 (12) to shelf #2 rail board assembled parts (2), (5), (6) by inserting wood dowels (A) into wood dowel holes on shelf #2 left rail board (5), shelf #2 right rail board (6) and rear rail board (2).
3. Insert 6 wood screws (E) through holes on shelf #2 (12) and tighten to shelf #2 left rail board (5), shelf #2 right rail board (6) and rear rail board (2).


STEP 7



STEP 7

1. Insert 6 wood dowels (A) into wood dowel holes on shelf #3 (13).
2. Attach shelf #3 (13) to shelf #3 rail board assembled parts (2), (7), (8) by inserting wood dowels (A) into wood dowel holes on shelf #3 left rail board (7), shelf #3 right rail board (8) and rear rail board (2).
3. Insert 6 wood screws (E) through holes on shelf #3 (13) and tighten to shelf #3 left rail board (7), shelf #3 right rail board (8) and rear rail board (2).


STEP 8



STEP 8

1. Insert 6 wood dowels (A) into wood dowel holes on shelf #4 (13).
2. Attach shelf #4 (13) to shelf #4 rail board assembled parts (2), (9), (10) by inserting wood dowels (A) into wood dowel holes on shelf #4 rail board (9), shelf #4 rail board (10) and rear rail board (2).
3. Insert 6 wood screws (E) through holes on shelf #4 (13) and tighten to shelf #4 left rail board (9), right rail board (10) and rear rail board (2).


STEP 9



STEP 9

1. Insert 2 wood dowels (A) into wood dowel holes on top bar (14).
2. Screw 2 cam bolts (B) into pre-threaded holes on top bar (14).
3. Attach top bar (14) to left front leg (15) and left rear leg (16) by inserting wood dowels (A) into wood dowel holes and inserting cam bolts (B) into cam lock holes on left front leg (15) and left rear leg (16).
4. Insert 2 cam locks (C) into cam lock holes on left front leg (15) and left rear leg (16), then rotate clockwise to secure cam bolts in place.
5. Repeat above steps to assemble another top bar (14) to right side front leg (17) and right side rear leg (18).


STEP 10



STEP 10

1. Attach pre-assembled shelf #1 to pre-assembled right-side frame by inserting 2 machine screws (D) through holes on right rail board (4) and tighten to pre-assembled right-side frame.
2. Repeat above step to assemble shelf #2, #3, #4 to pre-assembled right-side frame.


STEP 11



STEP 11

1. Attach pre-assembled shelf #1 to pre-assembled left-side frame by inserting 2 machine screws (D) through holes on left rail board (3) and tighten to pre-assembled left-side frame.
2. Repeat above step to assemble Shelf #2, #3, #4 to pre-assembled left-side frame.


STEP 12



STEP 12


1. Attach one bracket (J) to back of the ladder shelf by inserting 1 wood screw (G) through hole on bracket (J) and tighten into hole on top rear rail board (1).
2. Drill hole on wall according to the height of bracket (J) and insert plastic anchor (H).
3. Attach one bracket (J) to plastic anchor (H) on wall by inserting 1 wall screw (F) through hole on bracket (J) and tighten into plastic anchor (H).

STEP 13



STEP 13

1. Place the ladder shelf against the wall and close to bracket (J).
2. Insert plastic lock strap (K) through hole on bracket (J) assembled on ladder shelf, then through hole on bracket (J) on wall and fasten plastic lock strap (K) to fix brackets (J) firmly together.



ENJOY YOUR NEW RiverRidge® CABINET NOW!

Attention Adults: Cabinet should be checked periodically for damage or loose screws/parts. Take appropriate action necessary to correct hazards such as tightening of screws and taking any damaged parts away from children.

Warning  **Please make sure your item is secured to the wall, per assembly instructions.**

Thank you for purchasing this RiverRidge® Kids Products item. We hope you enjoy it and consider purchasing other RiverRidge® items.

Send requests for missing or damaged parts replacements by email to:

customer.service@ssi-rr.com or call toll free 1-(844)-223-5201 or order parts on line at

www.riverridgehome.com

RiverRidge® is a registered trademark of Sourcing Solutions, Inc., Hudson, WI 54016.

