




Replacement Parts List

Kiso 4" 1 Hdl Bath Faucet

MODEL	Internet SKU #	FINISH
HD67733W-6027D	301879676	Bronze



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to HOMEDEPOT.COM, and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Handle	RP1346727D		
2	Set Screw	RP50002		
3	Index	RP8039027D		
4	Cap	RP8055127D		
5	Bonnet Nut	RP70224		
6	Cartridge & Screw	RP20078	301158148	
7	Flange	RP8054827D		
8	Deck Plate	RP8054927D		

Part	Description	Part #	Internet SKU #	Store SKU #
9	Gasket	RP80550		
10	Rubber Washer	RP64008		
11	Metal Washer	RP64009		
12	Nut	RP56111		
13	ClickInstall™ drain assembly	RP4022827D		
14	Lift rod	RP4023027D		