




Item # 739 448
Model # 176-411-CL

USE AND CARE GUIDE

OAK CLIFF STEEL CHAISE LOUNGE



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8.00 a.m. - 7.00 p.m. EST, Monday - Friday,
9.00 a.m. - 6.00 p.m. EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this chaise lounge. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly	3
Safety Information.....	2	Planning Assembly.....	3
Warranty	2	Hardware Included.....	3
2 Year Frame and Fabric Limited Warranty	2	Package Contents	4
What Is Covered	2	Assembly	5
What Is Not Covered	2		
Care Instructions.....	2		

Safety Information



CAUTION: Please keep children out of the assembly area during assembly.



CAUTION: Use the chaise lounge on flat ground only.

Warranty

TWO YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for two years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Care Instructions

Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. Treat the frame with liquid wax for maximum protection against UV light and salty, damp air. When not in use, store the furniture in a cool, dry place. If your set includes cushions or mesh fabric, they may be cleaned by hand with a mild solution of soap and water. Rinse the cushions thoroughly and allow to drip dry. Do not machine wash or tumble dry, as cushions may shrink. Do not use bleach or solvents on fabrics.


You may contact our customer service department with any questions by phone at 1-855-HD-HAMPTON or visit www.hamptonbay.com.


Pre-Assembly

PLANNING ASSEMBLY

It will take two people about 20 minutes to complete the assembly process.

HARDWARE INCLUDED






**NOTE:** Hardware not shown to actual size.



Part	Description	Quantity
AA	Bolt cap (M6)	10
BB	Bolt (M6x20)	8
CC	Bolt (M6x35)	2
DD	Washer	10
EE	Hex wrench	1

Pre-Assembly (continued)

PACKAGE CONTENTS




Part	Description	Quantity
A	Back	1
B	Seat frame	1
C	Right armrest	1
D	Left armrest	1
E	Back cushion	1
F	Seat cushion	1

Assembly


1 Attach armrests

- Place the left armrest (D) on a flat, smooth surface.
- Attach the seat frame (B) to the armrest (D) with washers (DD) and bolts (BB) using the hex wrench (EE).
- Repeat the above step for the right armrest (C).
- Fully tighten all bolts once all bolts are in place and cover them with bolt caps (AA).



2 Attaching the back panel

- Attach the back panel (A) to the inner side of the seat frame (B) with washers (DD) and bolts (CC) using hex wrench (EE).
- Fully tighten all bolts and cover them with bolt caps (AA).



Assembly (continued)

3 Placing cushions

- ☐ Set the back panel (A) at desired position.
- ☐ Place cushions (E) and (F) on the chaise.
- ☐ Secure cushions (E) and (F) on the frame of the chaise.
- ☐ Level the chaise with glides at the bottom of middle legs.




CAUTION : Keep your fingers clear while switching the positions of the chaise lounge back.



WARNING: Do not use the chaise unless the back panel is firmly locked in your desired position.



WARNING: Do not try to switch the position of the back panel while you are still on the chaise.





Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service

8.00 a.m. - 7.00 p.m. EST, Monday - Friday,

9.00 a.m. - 6.00 p.m. EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.