




ROYALTON Equipment Sizing Guide



Use the map above to determine your region and compare to the chart below to find your application size.

95% AFUE Gas Furnace (Multi-Positional) Selection

Square Footage	Region 1	Region 2	Region 3	Region 4	Region 5	Furnace Model
	820-1025	885-1105	990-1235	1200-1500	1345-1680	95G1--045
	1025-1560	1105-1685	1235-1880	1500-2285	1680-2560	95G1--070
	1560-2075	1685-2235	1880-2500	2285-3035	2560-3400	95G1--090
	2075-2585	2235-2790	2500-3120	3035-3785	3400-4240	95G1--110
	2585-3120	2790-3370	3120-3765	3785-4570	4240-5120	95G1--135

Residential Sizing: The table and charts are intended to be used as a guideline for Residential applications only. The information is based on conventional window space (<15%), insulation and building construction (8 ft. ceiling height). When including a finished basement, use 1/2 of the finished basement square footage with the rest of the area being calculated.

Mobile/Manufactured Home Sizing: Refer to the Date Plate located in the electrical box or kitchen cabinets. For further assistance, call Hamilton's customer service department (800) 879-0123.