lavish home

Flameless LED Set with Remote & Timer Instruction(Product Code: 72-LZ3403A-CLR)

1. Remove and discard plastic tab from Remote Control battery compartment
2. Install 3xAAA batteries(not included) into the bottom battery compartment of each candle
3. Use the On-Off switch on the bottom of each candle to turn LED to the ON position
4. Instruction on remote control:



5. Remote Control Battery Replacement:see Diagram on back of Remote control
6. Timer instruction:when remote control 4H button is pressed,the candles will turn on for 4 hours and authomatically turn off for a perio of 20 hours.Candles will turn on and off at the same each day.Same principle of operation as 8H timer

Attention:

1. Keeping the candle away from fire or other high heat items otherwise the wax would melt.
2. Install batteries as indicated by the (+/-) polarity signs.
3. Dispose batteries as small chemical waste.
4. Never recharge non-rechargeable batteries.
5. Never throw batteries into fire.
6. Never mix new and old batteries or batteries of different types.
7. Never allow children to attempt to replace batteries.
8. For decoration use only,not a toy for children or pets

Protect the environment:

When this product reaches the end of its usefull life,please send it to the recycling site for the reccycling of electronic equipment.Please refer to the symbols on the product,the users' instruction or the packaging to decide the matching type.Please contact the local govement for the nearest recycling site in your neighborhood.